









TPS40422

ZHCS614F-OCTOBER 2011-REVISED JANUARY 2017

TPS40422 具有 PMBus™ 接口的双输出或双相同步

降压控制器

1 特性

- 单电源运行: 4.5V 至 20V
- 输出电压范围为 0.6V 至 5.6V
- 双输出或双相同步降压控制器
- PMBus™接口功能
 - 以 2mV 为步长的电压上升/下降
 - 可编程故障限制和响应
 - 输出电压,输出电流监控
 - 2N3904 外部温度监控晶体管
 - 可编程欠压闭锁 (UVLO) 开/关阈值
 - 可编程软启动时间和接通与关断延迟
- 片载非易失性存储器(NVM)用于存储定制配置
- 180°相移以减少输入纹波
- ±0的600mV基准电压从0°C至85°C,准确度5%
- 电感器分布式直流电阻(DCR)电流感应
- 可编程开关频率: 200kHz 至 1MHz
- 具有输入前反馈的电压模式控制
- 多相位运行的电流共享
- 支持预偏置输出
- 差分远程感应
- 外部SYNC
- 通过支持外部偏置电源切换的 BPEXT 引脚 提升了 效率
- OC、OV、UV 和 OT 故障保护
- 40 引脚、6mm × 6mm、0.5mm 间距 VQFN 封装
- 40 引脚、5mm×5mm、0.4mm 间距 WQFN 封装
- 使用 **TPS40422** 器件并借助 WEBENCH® 电源设计器创建定制设计方案
- 2 应用
- 多重电源轨系统
- 电信基站
- 交换机/路由器网络
- 服务器和存储系统

3 说明

TPS40422 是一款双输出 **PMBus** 协议同步降压控制器。它也可配置为单一的双向输出。

其宽输入范围支持 5V 和 12V 中间总线。准确的基准 电压满足了最新 ASIC 的精度电压的需要并且有可能减 少了输出电容。电压模式控制降低噪声敏感度并保证低 占空比转换。

器件信息⁽¹⁾

器件型号	封装	封装尺寸(标称值)			
TDC 40422	VQFN (40)	6.00mm x 6.00mm			
1P540422	WQFN (40)	5.00mm × 5.00mm			

(1) 如需了解所有可用封装,请参阅数据表末尾的可订购产品附录。





简化应用

目录

1 2 3 4	特应 说 修订	·····································
5	说明	(续)3
6	Pin	Configuration and Functions 4
7	Spe	cifications7
	7.1	Absolute Maximum Ratings 7
	7.2	ESD Ratings 7
	7.3	Recommended Operating Conditions 7
	7.4	Electrical Characteristics
	7.5	Typical Characteristics 12
8	Deta	ailed Description 13
	8.1	Overview 13
	8.2	Functional Block Diagram 14
	8.3	Feature Description 15
	8.4	Device Functional Modes

4 修订历史记录

注: 之前版本的页码可能与当前版本有所不同。

Changes from Revision E (September 2016) to Revision F

•	已添加 向 <i>器件信息</i> 表添加了 WQFN 封装	1
•	Added WQFN package drawing	5

Changes from Revision D (August 2014) to Revision E

•	Added pins (CS1N, CS2N, CS1P, CS2P, GSNS1, and GSNS2) to <i>Input voltage range</i> specification in Absolute Maximum Ratings table	7
•	Updated VSNSx connection description in Table 1	23
•	Updated VSNS2 connection description in Table 2	26
•	Corrected Equation 23	56
•	Clarified Table 9	57

	8.5	Programming	27
	8.6	Register Maps	28
9	App	lication and Implementation	52
	9.1	Application Information	<mark>52</mark>
	9.2	Typical Application	<mark>52</mark>
10	Pow	ver Supply Recommendations	<mark>62</mark>
11	Lay	out	<mark>63</mark>
	11.1	Layout Guidelines	<mark>63</mark>
	11.2	Layout Example	<mark>64</mark>
12	器件	和文档支持	<mark>65</mark>
	12.1	器件支持	<mark>65</mark>
	12.2	社区资源	65
	12.3	商标	<mark>65</mark>
	12.4	静电放电警告	<mark>65</mark>
	12.5	Glossary	<mark>65</mark>
13	机械	、封装和可订购信息	<mark>65</mark>



www.ti.com.cn

Page

Page

Changes from Revision C (August 2012) to Revision D

•	添加了处理额定值表、特性说明部分,器件功能模式部分,应用和实施部分,电源相关建议部分,布局部分,器件和 文档支持部分以及机械、封装和可订购信息部分	1
•	更正了简化应用。	1
•	Updated FB2 description in table	6
•	Changed maximum input voltage range for VDD from "20 V" to "22 V" in Absolute Maximum Ratings table	7
•	Corrected maximum input voltage range for CLK, DATA, and SYNC to "5.5 V" in Absolute Maximum Ratings table	7
•	Corrected maximum input voltage range for CNTL1, CNTL2 to "7 V" in Absolute Maximum Ratings table	7
•	Corrected maximum output voltage range for SMBALRT in Absolute Maximum Ratings table	7
•	Updated specifications in PMBus INTERFACE section of Electrical Characteristics table	11
•	Added Switching Node and BOOT Voltage section	20
•	Changed section title from User Data and Adjustable Anti-Cross Conduction Delay to User Data	23
•	Updated User Data section	23
•	Added Adjustable Anti-Cross Conduction Delay section	23
•	Added Table 4	29

5 说明 (续)

根据 PMBus 协议,该器件的裕量调节功能、基准电压、故障限制、欠压闭锁 (UVLO) 阈值、软启动时间以及接通 和关断延迟均可编程设定。

此外,该器件采用精准的测量系统对每个通道的输出电压,电流和温度进行监控。

ZHCS614F-OCTOBER 2011-REVISED JANUARY 2017

Page



TPS40422 ZHCS614F – OCTOBER 2011 – REVISED JANUARY 2017



www.ti.com.cn

6 Pin Configuration and Functions







Pin Functions

PIN	NO.	I/O	DESCRIPTION
ADDR0	10	I	Low-order address pin for PMBus address configuration. One of eight resistor values must be connected from this pin to AGND to select the low-order octal digit in the PMBus address.
ADDR1	9	I	High-order address pin for PMBus address configuration. One of eight resistor values must be connected from this pin to AGND to select the high-order octal digit in the PMBus address.
AGND	6	_	Low-noise ground connection to the controller. Connections should be arranged so that power level currents do not flow through the AGND path.
BOOT1	30	I	Bootstrapped supply for the high-side FET driver for channel 1 (CH1). Connect a capacitor (100 nF typical) from BOOT1 to SW1 pin.
BOOT2	20	I	Bootstrapped supply for the high-side FET driver for channel 2 (CH2). Connect a capacitor (100 nF typical) from BOOT2 to SW2 pin.
BP3	32	0	Output bypass for the internal 3.3-V regulator. Connect a 100 nF or larger capacitor from this pin to AGND. The maximum suggested capacitor value is 10 μ F.
BP6	25	0	Output bypass for the internal 6.5-V regulator. Connect a low ESR, 1 μ F or larger ceramic capacitor from this pin to PGND. The maximum suggested capacitor value is 10 μ F.
BPEXT	24	I	External voltage input for BP6 switchover function. If the BPEXT function is not used, connect this pin to PGND via a 10-k Ω resistor. Otherwise connect a 100-nF or larger capacitor from this pin to PGND. The maximum suggested capacitor value is 10 μ F.
CLK	12	I	Clock input for the PMBus interface. Pull up to 3.3 V with a resistor.
CNTL1	4	I	Logic level input which controls startup and shutdown of CH1, determined by PMBus options. When floating, the pin is pulled up to BP6 by an internal 6-µA current source.

TPS40422 ZHCS614F – OCTOBER 2011 – REVISED JANUARY 2017

www.ti.com.cn

NSTRUMENTS

Texas

Pin Functions (continued)

PIN	NO.	I/O	DESCRIPTION	
CNTL2	5	I	Logic level input which controls startup and shutdown of CH2, determined by PMBus options. When floating, the pin is pulled up to BP6 by an internal 6-µA current source.	
COMP1	3	0	Output of the error amplifier for CH1 and connection node for loop feedback components.	
COMP2	7	0	Output of the error amplifier for CH2 and connection node for loop feedback components. For two-phase operation, use COMP1 for loop feedback and connect COMP1 to COMP2.	
CS1N	35	I	Negative terminal of current sense amplifier for CH1.	
CS2N	17	I	Negative terminal of current sense amplifier for CH2.	
CS1P	34	I	Positive terminal of current sense amplifier for CH1.	
CS2P	18	I	Positive terminal of current sense amplifier for CH2.	
DATA	11	I/O	Data input/output for the PMBus interface. Pull up to 3.3 V with a resistor.	
DIFFO1	39	0	Output of the differential remote sense amplifier for CH1.	
FB1	2	I	Inverting input of the error amplifier for CH1. Connect a voltage divider to FB1 between DIFFO1 and AGND to program the output voltage for CH1.	
FB2	8	I	Inverting input of the error amplifier for CH2. Connect a voltage divider to FB2 between VOUT2 and GND to program the output for CH2. For two-phase operation, use FB1 to program the output voltage and connect FB2 to BP6 before applying voltage to VDD.	
GSNS1	38	I	Negative terminal of the differential remote sense amplifier for CH1.	
GSNS2	14	I	Negative terminal of the differential remote sense amplifier for CH2.	
HDRV1	29	0	Bootstrapped gate drive output for the high-side N-channel MOSFET for CH1.	
HDRV2	21	0	Bootstrapped gate drive output for the high-side N-channel MOSFET for CH2.	
LDRV1	27	0	Gate drive output for the low side synchronous rectifier N-channel MOSFET for CH1.	
LDRV2	23	0	Gate drive output for the low-side synchronous rectifier N-channel MOSFET for CH2.	
PGND	26	_	Power GND.	
PG1	33	0	Open drain power good indicator for CH1 output voltage.	
PG2	19	0	Open drain power good indicator for CH2 output voltage.	
RT	1	I	Frequency programming pin. Connect a resistor from this pin to AGND to set the oscillator frequency.	
SMBALRT	13	0	Alert output for the PMBus interface. Pull up to 3.3 V with a resistor.	
SW1	28	I	Return of the high-side gate driver for CH1. Connect to the switched node for CH1.	
SW2	22	I	Return of the high-side gate driver for CH2. Connect to the switched node for CH2.	
SYNC	40	I	Logic level input for external clock synchronization. When an external clock is applied to this pin, the controller oscillator is synchronized to the external clock and the switching frequency is one half of the external clock frequency. When an external clock is not used, tie this pin to AGND.	
TSNS1	36	I	External temperature sense input for CH1.	
TSNS2	16	I	External temperature sense input for CH2.	
VDD	31	I	Power input to the controller. Connect a low ESR, 100 nF or larger ceramic capacitor from this pin to AGND.	
VSNS1	37	I	Positive terminal of the differential remote sense amplifier for CH1.	
VSNS2	15	I	Positive terminal of the differential remote sense amplifier for CH2.	



7 Specifications

7.1 Absolute Maximum Ratings

over operating free-air temperature range (unless otherwise noted) ⁽¹⁾

		MIN	MAX	UNIT		
	VDD	-0.3	22			
	BOOT1, BOOT2, HDRV1, HDRV2	-0.3	30			
Input voltage range ⁽²⁾	BOOT1 - SW1, BOOT2 - SW2	-0.3	7	V		
input voltage range	CLK, DATA, SYNC	-0.3	5.5	v		
	BPEXT, CNTL1, CNTL2, CS1N, CS2N, CS1P, CS2P, FB1, FB2, GSNS1, GSNS2, VSNS1, VSNS2	-0.3	7			
	BP6, COMP1, COMP2, DIFFO1, LDRV1, LDRV2, PG1, PG2	-0.3	7			
Output voltage repge $^{(3)}$	SMBALRT	-0.3	5.5	V		
	SW1, SW2	-1	30	v		
	ADDR0, ADDR1, BP3, RT, TSNS1, TSNS2	-0.3	3.6			
Operating junction tempera	iture, T _J	-40	150	°C		

(1) Stresses beyond those listed under Absolute Maximum Ratings may cause permanent damage to the device. These are stress ratings only, which do not imply functional operation of the device at these or any other conditions beyond those indicated under Recommended Operating Conditions. Exposure to absolute-maximum-rated conditions for extended periods may affect device reliability.

(2) All voltage values are with respect to the network ground pin unless otherwise noted.

(3) Voltage values are with respect to the SW pin.

7.2 ESD Ratings

			MIN	MAX	UNIT	
T _{stg}	Storage temperature ran	orage temperature range		155	°C	
V _(ESD)	Electrostatic discharge	Human body model (HBM), per ANSI/ESDA/JEDEC JS-001, all pins ⁽¹⁾	2			
		Charged device model (CDM), per JEDEC specification JESD22-C101, all pins ⁽²⁾	1.5		κV	

(1) JEDEC document JEP155 states that 500-V HBM allows safe manufacturing with a standard ESD control process.

(2) JEDEC document JEP157 states that 250-V CDM allows safe manufacturing with a standard ESD control process.

7.3 Recommended Operating Conditions

over operating free-air temperature range (unless otherwise noted)

		MIN	MAX	UNIT
VDD	Input operating voltage	4.5	20	V
TJ	Operating junction temperature	-40	125	°C

TPS40422

ZHCS614F-OCTOBER 2011-REVISED JANUARY 2017

STRUMENTS www.ti.com.cn

EXAS

7.4 Electrical Characteristics

T_J = -40°C to 125°C, V_{IN} = V_{DD} = 12 V, f_{SW} = 500 kHz, all parameters at zero power dissipation (unless otherwise noted)

	PARAMETER	TEST CONDITIONS	MIN	TYP	MAX	UNIT			
INPUT SUPPLY									
V _{VDD}	Input supply voltage range		4.5		20	V			
I _{VDD}		Switching, no driver load		18	25	0			
	input operating current	Not switching		15	20	mA			
UVLO									
V _{IN(on)}	Input turn on voltage ⁽¹⁾	Default settings		4.25		V			
V _{IN(off)}	Input turn off voltage ⁽¹⁾	Default settings		4		V			
V _{INON(rng)}	Programmable range for turn on voltage		4.25		16	V			
VINOFF(rng)	Programmable range for turn off voltage		4		15.75	V			
VINONOFF(acc)	Turn on and turn off voltage accuracy ⁽²⁾	4.5 V \leq V _{VDD} \leq 20 V, all VIN_ON and VIN_OFF settings	-5%		5%				
ERROR AMPLI	FIER								
	- - - - -	0°C ≤ T _J ≤ 85°C	597	600	603				
V _{FB}	Feedback pin voltage	$-40^{\circ}C \le T_{J} \le 125^{\circ}C$	594	600	606	mV			
A _{OL}	Open-loop gain ⁽²⁾		80			dB			
G _{BWP}	Gain bandwidth product ⁽²⁾			24		MHz			
I _{FB}	FB pin bias current (out of pin)	V _{FB} = 0.6 V			50	nA			
	Sourcing	V _{FB} = 0 V	1	3					
COMP	Sinking	V _{FB} = 1 V	3	9		mA			
BP6 REGULAT	OR								
V	Output voltage	$I_{BP6} = 10 \text{ mA}$	6.2	6.5	6.8	V			
VBP6	Dropout voltage	$V_{\text{VIN}}-V_{\text{BP6}},V_{\text{VDD}}$ = 4.5 V, I_{BP6} = 25 mA		70	120	mV			
I _{BP6}	Output current	$V_{VDD} = 12 V$	120			mA			
V _{BP6UV}	Regulator UVLO voltage ⁽²⁾		3.3	3.55	3.8	V			
V _{BP6UV(hyst)}	Regulator UVLO voltage hysteresis ⁽²⁾		230	255	270	mV			
BPEXT									
V _{BPEXT(swover)}	BPEXT switch-over voltage		4.5	4.6		V			
V _{hys(swover)}	BPEXT switch-over hysteresis		100		200	mV			
V _{BPEXT(do)}	BPEXT dropout voltage	V_{BPEXT} – V_{BP6} , V_{BPEXT} = 4.8 V, I_{BP6} = 25 mA			100	mV			
BOOTSTRAP									
V _{BOOT(drop)}	Bootstrap voltage drop	I _{BOOT} = 5 mA		0.7	1.0	V			
BP3 REGULAT	OR								
V _{BP3}	Output voltage	V_{VDD} = 4.5 V, $I_{BP3} \le 5 \text{ mA}$	3.1	3.3	3.5	V			
OSCILLATOR	1								
four	Adjustment range		100		1000	kHz			
'5₩	Switching frequency	R _{RT} = 40 kΩ	450	500	550	kHz			
V _{RMP}	Ramp peak-to-peak ⁽²⁾			V _{VDD} /8.2		V			
V _{VLY}	Valley voltage ⁽²⁾		0.7	0.8	1.0	V			

Hysteresis of at least 150 mV is specified by design.
 Specified by design. Not production tested.



Electrical Characteristics (continued)

T_J = -40°C to 125°C, V_{IN} = V_{DD} = 12 V, f_{SW} = 500 kHz, all parameters at zero power dissipation (unless otherwise noted)

	PARAMETER	TEST CONDITIONS	MIN	TYP	MAX	UNIT
SYNCHRONIZ	ATION	•				
V _{SYNCH}	SYNC high-level threshold		2.0			V
V _{SYNCL}	SYNC low level threshold				0.8	V
t _{SYNC}	Minimum SYNC pulse width				100	ns
f _{SYNC(max)}	Maximum SYNC frequency ⁽³⁾		2000			kHz
f _{SYNC(min)}	Minimum SYNC frequency ⁽³⁾				200	
	SYNC frequency range (increase from nominal oscillator frequency)		-20%		20%	
PWM						
t _{OFF(min)}	Minimum off time		90	100		ns
t _{ON(min)}	Minimum on pulse ⁽²⁾			90	130	ns
		HDRV off to LDRV on	15 30 4		45	
t _{DEAD}	Output driver dead time	LDRV off to HDRV on	15	30	45	ns
SOFT START						
	Soft-start time	Factory default settings	2.4	2.7	3.0	ms
t _{SS}	Accuracy over range ⁽²⁾	600 µs ≤ t _{SS} ≤ 9 ms	-15%		15%	
t _{ON(delay)}	Turn-on delay time ⁽⁴⁾	Factory default settings		0		ms
t _{OFF(delay)}	Turn-off delay time	Factory default settings		0		ms
REMOTE SENS	SE AMPLIFIER		- I			
		$(V_{SNS1} - G_{SNS1}) = 0.6 V$	-5		5	5 3 mV 7
V _{DIFFO(err)}	Error voltage from DIFFO1 to (V _{SNS1} - G _{SNS1})	(V _{SNS1} - G _{SNS1}) = 1.2 V	-8		8	
2		(V _{SNS1} -G _{SNS1}) = 3.0 V	-17		17	
BW	Closed-loop bandwidth ⁽²⁾		2			MHz
V _{DIFFO(max)}	Maximum DIFFOx output voltage		V _{BP6} -0.2			V
	Sourcing		1			
IDIFFO	Sinking		1			mA
DRIVERS			_			
R _{HS(up)}	High-side driver pull-up resistance	$(V_{BOOT} - V_{SW}) = 6.5 \text{ V}, I_{HS} = -40 \text{ mA}$	0.8	1.5	2.5	
R _{HS(dn)}	High-side driver pull-down resistance	$(V_{BOOT} - V_{SW}) = 6.5 \text{ V}, \text{ I}_{HS} = 40 \text{ mA}$	0.5	1.0	1.5	0
R _{LS(up)}	Low-side driver pull-up resistance	I _{LS} = -40 mA	0.8	1.5	2.5	Ω
R _{LS(dn)}	Low-side driver pull-down resistance	I _{LS} = 40 mA	0.35	0.70	1.40	
t _{HS(rise)}	High-side driver rise time (2)	C _{LOAD} = 5 nF		15		
t _{HS(fall)}	High-side driver fall time ⁽²⁾	C _{LOAD} = 5 nF		12		
t _{LS(rise)}	Low-side driver rise time ⁽²⁾	C _{LOAD} = 5 nF		15		ns
t _{LS(fall)}	Low-side driver fall time (2)	C _{LOAD} = 5 nF		10		
CURRENT SEM	ISING AMPLIFIER					
V _{CS(rng)}	Differential input voltage range	V _{CSxP} -V _{CSxN}	-60		60	mV
V _{CS(cmr)}	Input common-mode range		0		V _{BP6} -0.2	V
V _{CS(os)}	Input offset voltage	$V_{CSxP} = V_{CSxN} = 0 V$	-3		3	mV
A _{CS}	Current sensing gain			15.00		V/V
V _{CS(out)}	Amplfier output	$(V_{CSxP} - V_{CSxN}) = 20 \text{ mV}$	270	300	330	mV
f _{C0}	Closed-loop bandwidth ⁽²⁾		3	5		MHz
.,		$ (V_{CS1P} - V_{CS1N}) = (V_{CS2P} - V_{CS2N}) = 20 \text{ mV}, $	-5.00%		5.00%	
V _{CS(chch)}	Amplifier output difference between CH1, CH2	$(V_{CS1P} - V_{CS1N}) = (V_{CS2P} - V_{CS2N}) = 20 \text{ mV},$ T _J = 85°C	-6.67%		6.67%	

When using SYNC, the switching frequency is set to one-half the SYNC frequency. The minimum turn-on delay is 50 μs , when TON_DELAY is set to a factor of zero. (3)

(4)

Electrical Characteristics (continued)

	PARAMETER	TEST CONDITIONS	MIN	TYP	MAX	UNIT
CURRENT LIM	т					
t _{OFF(oc)}	Off-time between restart attempts	Hiccup mode		7×t _{SS}		ms
		Factory default settings		0.488		-
DCR	Inductor DCR current sensing calibration value	Programmable range	0.240		15.500	mΩ
I _{OC(fit)}		Factory default settings		30		•
	Output current overcurrent fault threshold	Programmable range	3		50	A
		Factory default settings		27		•
IOC(warn)	Output current overcurrent warning threshold	Programmable range	2		49	А
I _{OC(tc)}	Output current fault/warning temperature coefficient ⁽²⁾		3900	4000	4100	ppm/°C
I _{OC(acc)}	Output warning and fault accuracy	$(V_{CSxP}-V_{CSxN}) = 30 \text{ mV}$	-15%		15%	
PGOOD						
V _{FBPGH}	FB PGOOD high threshold	Factory default settings		675		mV
V _{FBPGL}	FB PGOOD low threshold	Factory default settings		525		mV
V _{PG(acc)}	PGOOD accuracy over range	$4.5 \text{ V} \le \text{V}_{\text{VDD}} \le 20 \text{ V},$ $468 \text{ mV} \le \text{V}_{\text{PGOOD}} \le 675 \text{ mV}$	-4%		4%	
V _{pg(hyst)}	FB PGOOD hysteresis voltage			25	40	mV
R _{PGOOD}	PGOOD pulldown resistance	V _{FB} = 0, I _{PGOOD} = 5 mA		40	70	Ω
I _{PGOOD(lk)}	PGOOD pin leakage current	No fault, V _{PGOOD} = 5 V			20	μA
OUTPUT OVER	VOLTAGE/UNDERVOLTAGE					
V _{FBOV}	FB pin over voltage threshold	Factory default settings		700		mV
V _{FBUV}	FB pin under voltage threshold	Factory default settings		500		mV
V _{UVOV(acc)}	FB UV/OV accuracy over range	$4.5 \text{ V} \le \text{V}_{\text{VDD}} \le 20 \text{ V}$	-4%		4%	
OUTPUT VOLT	AGE TRIMMING AND MARGINING					
V _{FBTM(step)}	Resolution of FB steps with trim and margin			2		mV
t _{FBTM(step)}	Transition time per trim or margin step	After soft-start time		30		μs
V _{FBTM(max)}	Maximum FB voltage with trim and/or margin			660		mV
	Minimum FB voltage with trim or margin only			480		
V _{FBTM(min)}	Minimum FB voltage range with trim and margin combined			420		mV
V _{FBMH}	Margin high FB pin voltage	Factory default settings		660		mV
V _{FBML}	Margin low FB pin voltage	Factory default settings		540		mV
TEMPERATUR	E SENSE AND THERMAL SHUTDOWN					
T _{SD}	Junction thermal shutdown temperature ⁽²⁾		135	145	155	°C
T _{HYST}	Thermal shutdown hysteresis ⁽²⁾		15	20	25	°C
I _{TSNS(ratio)}	Ratio of bias current flowing out of TSNS pin, state 2 to state 1		9.7	10.0	10.3	
I _{TSNS}	State 1 current out of TSNSx pin ⁽²⁾			10		μA
I _{TSNS}	State 2 current out of TSNSx pin ⁽²⁾			100		μA
V _{TSNS}	Voltage range on TSNSx pin ⁽²⁾		0		1.00	V
T _{SNS(acc)}	External temperature sense accuracy ⁽²⁾	$0^{\circ}C \le T_{J} \le 125^{\circ}C$	-5		5	°C
T _{OT(flt)}	Overtemperature fault limit ⁽²⁾	Factory default settings		145		°C
	OT fault limit range ⁽²⁾		120		165	°C
T _{OT(warn)}	Overtemperature warning limit ⁽²⁾	Factory default settings		125		°C
	OT warning limit range ⁽²⁾		100		140	°C
T _{OT(step)}	OT fault/warning step			5		°C
T _{OT(hys)}	OT fault/warning hysteresis ⁽²⁾		15	20	25	°C



Electrical Characteristics (continued)

 $T_J = -40^{\circ}C$ to 125°C, $V_{IN} = V_{DD} = 12$ V, $f_{SW} = 500$ kHz, all parameters at zero power dissipation (unless otherwise noted)

	PARAMETER	TEST CONDITIONS	MIN	TYP	MAX	UNIT
MEASUREMEN	NT SYSTEM					
M _{VOUT(rng)}	Output voltage measurement range (5)		0.5		5.8	V
M _{VOUT(acc)}	Output voltage measurement accuracy	V _{OUT} = 1.0 V	-2.0%		2.0%	
		V_{CSxP} - V_{CSxN} , 0.2440 mΩ ≤ IOUT_CAL_GAIN ≤ 0.5795 mΩ	0		24	
M _{IOUT(rng)}	Output current measurement signal range ⁽⁵⁾	V_{CSxP} - V_{CSxN} , 0.5796 mΩ ≤ IOUT_CAL_GAIN ≤ 1.1285 mΩ	0		40	mV
		V_{CSxP} - V_{CSxN} , 1.1286 mΩ ≤ IOUT_CAL_GAIN ≤ 15.5 mΩ	0		60	
M _{IOUT(acc)}	Output current measurement accuracy	$I_{OUT} \ge 20 \text{ A}, \text{ DCR} = 0.5 \text{ m}\Omega$	-1.0		1.0	А
PMBus ADDR	ESSING					
I _{ADD}	Address pin bias current		9.24	10.50	11.76	μA
PMBus INTER	FACE					
V _{IH}	Input high voltage, CLK, DATA, CNTLx		2.1			V
V _{IL}	Input low voltage, CLK, DATA, CNTLx				0.8	V
I _{IH}	Input high level current, CLK, DATA		-10		10	μA
I _{IL}	Input low level current, CLK, DATA		-10		10	mA
I _{CTNL}	CNTL pin pull-up current			6		μA
V _{OL}	Low-level output voltage, DATA, (5)	$4.5 \text{ V} \le \text{V}_{\text{VDD}} \le 20 \text{ V}, \text{ I}_{\text{OUT}} = 4 \text{ mA}$			0.4	V
I _{OH}	High-level output open-drain leakage current, DATA, SMBALRT	V _{OUT} = 5.5 V	0		10	μA
C _{OUT}	Output capacitance, CLK, DATA ⁽⁵⁾				1	pF
F _{PMB}	PMBus operating frequency range ⁽⁵⁾	Slave mode	10		400	kHz
t _{BUF}	Bus free time between START and STOP ⁽⁵⁾		1.3			μs
t _{HD:STA}	Hold time after repeated START ⁽⁵⁾		0.6			μs
t _{SU:STA}	Repeated START setup time ⁽⁵⁾		0.6			μs
t _{SU:STO}	STOP setup time ⁽⁵⁾		0.6			μs
		Receive mode	0			
^L HD:DAT		Transmit mode	300			ns
t _{SU:DAT}	Data setup time ⁽⁵⁾		100			ns
t _{TIMEOUT}	Error signal/detect ⁽⁵⁾		25		35	ms
t _{LOW:MEXT}	Cumulative clock low master extend time ⁽⁵⁾				10	ms
t _{LOW:SEXT}	Cumulative clock low slave extend time ⁽⁵⁾				25	μs
t _{LOW}	Clock low time ⁽⁵⁾		1.3			μs
t _{HIGH}	Clock high time ⁽⁵⁾		0.6			μs
t _{FALL}	CLK/DATA fall time ⁽⁵⁾				300	ns
t _{RISE}	CLK/DATA rise time ⁽⁵⁾				300	ns

(5) Specified by design. Not production tested.

TPS40422 ZHCS614F – OCTOBER 2011 – REVISED JANUARY 2017



www.ti.com.cn

7.5 Typical Characteristics





Typical Characteristics (continued)



8 Detailed Description

8.1 Overview

The device is a flexible synchronous buck controller. It can be used as a dual-output controller, or as a twophase single-output controller. It operates with a wide input range from 4.5 V to 20 V and generates accurate regulated output as low as 600 mV.

In dual output mode, voltage mode control with input feed-forward architecture is implemented. With this architecture, the benefits are less noise sensitivity, no control instability issues for small DCR applications, and a smaller minimum controllable on-time, often desired for high conversion ratio applications.

In two-phase single-output mode, a current-sharing loop is implemented to ensure a balance of current between phases. Because the induced error current signal to the loop is much smaller when compared to the PWM ramp amplitude, the control loop is modeled as voltage mode with input feed-forward.

DESIGN NOTE

To operate the device in two-phase mode, tie the FB2 pin to the BP6 pin and tie the COMP1 pin to the COMP2 pin. These connections must be made before applying voltage to the VDD pin.

(See the *Two-Phase Mode Operation* section for more information)



8.2 Functional Block Diagram





8.3 Feature Description

8.3.1 PMBus Interface Protocol General Description

Timing and electrical characteristics of the PMBus protocol can be found in the PMB Power Management Protocol Specification, Part 1, revision 1.1 available at http://pmbus.org. The device supports both the 100 kHz and 400 kHz bus timing requirements. The device does not stretch pulses on the PMBus interface when communicating with the master device.

Communication over the PMBus interface can either support the Packet Error Checking (PEC) scheme or not. If the master supplies CLK pulses for the PEC byte, it is used. If the CLK pulses are not present before a STOP, the PEC is not used.

The device supports a subset of the commands in the PMBus 1.1 specification. Most controller parameters can be programmed using the PMBus interface and stored as defaults for later use. All commands that require data input or output use the linear format. The exponent of the data words is fixed at a reasonable value for the command and altering the exponent is not supported. Direct format data input or output is not supported by the device. See the *Supported Commands* section for specific details.

The device also supports the SMBALERT response protocol. The SMBALERT response protocol is a mechanism by which a slave (the device) can alert the bus master that it wants to talk. The master processes this event and simultaneously accesses all slaves on the bus (that support the protocol) through the alert response address. Only the slave that caused the alert acknowledges this request. The host performs a modified receive byte operation to get the slave's address. At this point, the master can use the PMBus status commands to query the slave that caused the alert. For more information on the SMBus alert response protocol, see the System Management Bus (SMBus) specification.

The device uses non-volatile memory to store configuration settings and scale factors. However, the device does not automatically save the programmed settings into this non-volatile memory. The STORE_USER_ALL command must be used to commit the current settings to non-volatile memory as device defaults. The detailed description of each setting notes if it is able to be stored in non-volatile memory.

8.3.2 Voltage Reference

The 600-mV bandgap cell connects internally to the non-inverting input of the error amplifier. The device trims the reference voltage by using the error amplifier in a unity gain configuration to remove amplifier offset from the final regulation voltage. The 0.5-% tolerance on the reference voltage allows the user to design a very accurate power supply.

8.3.3 Output Voltage

The device sets the output voltage in a way that is very similar to a traditional analog controller by using a voltage divider from the output to the FB (feedback) pin. The output voltage must be divided down to the nominal reference voltage of 600 mV. Figure 9 shows the typical connections for the controller. The device senses the voltage at the load by using the unity gain differential voltage sense amplifier. This functionality provides better load regulation for output voltages lower than 5-V nominal (see the *Electrical Characteristics* table for the maximum output voltage specification for the differential sense amplifier). For output voltages above this level, connect the output voltage directly to the junction of R1 and C1, leave DIFFO1 open, and do not connect the VSNS1 pin to the output voltage. The differential amplifier may also be used elsewhere in the overall system as a voltage buffer, provided the electrical specifications are not exceeded.



Feature Description (continued)



Figure 9. Setting the Output Voltage

The components shown in Figure 9 that determine the nominal output voltage are R1 and R2. In most cases, choose a value for R to ensure the feedback compensation values (R3, R4, C1, C2 and C3) come close to readily available standard values. A value for R2 is then calculated in Equation 1.

$$R2 = V_{FB} \times \left(\frac{R1}{\left(V_{OUT} - V_{FB}\right)}\right)$$

where

- V_{FB} is the feedback voltage
- V_{OUT} is the desired output voltage
- R1 and R2 are in the same unit

(1)

DESIGN NOTE

There is no DIFFO2 pin. In dual-output mode, VSNS2 and GSNS2 are connected to the load for channel 2 and the device uses the DIFFO2 signal internally to provide voltage monitoring. Connect the output directly to the junction of R1 and C1 for channel 2 to set the output voltage and for feedback.

The DIFFO1 pin operates at voltages up to (V_{BP6} –0.2 V). If the voltage between the VSNS1 and GSNS1 pins is higher than (V_{BP6} –0.2 V) during any condition, the output voltage moves out of regulation because the DIFFO1 voltage is limited by BP6. To prevent this from happening, the BP6 voltage must be pre-biased before the PWM turns on, and (V_{BP6} –0.2 V) must remain higher than the voltage between the VSNS1 and GSNS1 pins until the PWM turns off.

The feedback voltage can be changed to a value between -30% and +10% from the nominal 600 mV using PMBus commands. This adjustment allows the output voltage to vary by the same percentage. See the *Supported PMBus Commands* section for more details.

8.3.4 Voltage Feed Forward

The device uses input-voltage feed-forward topology that maintains a constant power stage gain when the input voltage varies. It also provides for very good response to input voltage transient disturbances. The constant power stage gain of the controller greatly simplifies feedback loop design because loop characteristics remain constant as the input voltage changes, unlike a buck converter without voltage feed-forward topology. For modeling purposes, the gain from the COMP pin to the average voltage at the input of the L-C filter is 8.2 V/V.



Feature Description (continued)

8.3.5 Current Sensing

The device uses a differential current-sense scheme to sense the output current. The sense element can be either the series resistance of the power stage filter inductor or a separate current sense resistor. When using the inductor series resistance as in Figure 10, a filter must be used to remove the large AC component of voltage across the inductor and leave only the component of the voltage that appears across the resistance of the R-C filter should be equal to or greater than the time constant of the inductor itself. If the time constants are equal, the voltage appearing across C4 is the current in the inductor multiplied the inductor resistance. The voltage across C4 perfectly reflects the inductor ripple current. Therefore, there is no need to have a shorter R-C time constant.

Extending the R-C filter time constant beyond the inductor time constant lowers the AC ripple component of voltage present at the current sense pins of the device, but allows the correct DC current information to remain intact. This extension also delays slightly the response to an overcurrent event, but reduces noise in the system leading to cleaner overcurrent performance and current reporting data over the PMBus interface.

$$R5 \times C4 \ge \left(\frac{L}{R_{DCR}}\right)$$

where (from Figure 10)

- R5 and R_{ESR} are in Ω
- C4 is in F (suggest 100 nF, 10⁻⁷F)
- L is in H

(2)

device is designed to accept a maximum voltage of 60 mV across the current-sense pins. Most inductors have a copper conductor which results in a fairly large temperature coefficient of resistance. Because of this large temperature coefficient, the resistance of the inductor and the current through the inductor should make a peak voltage less than 60 mV when the inductor is at the maximum temperature for the converter. This situation also applies for the external resistor in Figure 11. The full-load output current multiplied by the sense resistor value, must be less than 60 mV at the maximum converter operating temperature.

In all cases, C4 should be placed as close to the current sense pins as possible to help avoid problems with noise.



Figure 10. Current Sensing Using Inductor Resistance



Figure 11. Current Sensing Using Sense Resistor

After choosing the current sensing method, set the current-sense element resistance. This value allows the proper calculation of thresholds for the overcurrent fault and warning, as well as more accurate reporting of the actual output current. The IOUT_CAL_GAIN command is used to set the value of the sense element resistence of the device. IOUT_OC_WARN_LIMIT and IOUT_OC_FAULT_LIMIT set the levels for the overcurrent warning and fault levels respectively. (See the *Supported PMBus Commands* section for more details.)

Feature Description (continued)

8.3.6 Overcurrent Protection

The device has overcurrent fault and warning thresholds for each channel which can be independently set, when operating in dual-output mode. When operating in two-phase mode, both channels share the same overcurrent fault and warning thresholds. The overcurrent thresholds are set via the PMBus interface using the IOUT_OC_FAULT_LIMIT and IOUT_OC_WARN_LIMIT commands. (See the *Supported PMBus Commands* section for more details.)

The device generates an internal voltage corresponding to the desired overcurrent threshold, using the IOUT_OC_FAULT_LIMIT threshold and the IOUT_CAL_GAIN setting, and adjusting for temperature using the measured external temperature value. The current sense amplifier amplifies the sensed current signal with a fixed gain of 15 and then compares that value to this internal voltage threshold. The device uses a similar structure to activate an overcurrent warning based on the IOUT_OC_WARN_LIMIT threshold.



Figure 12. Overcurrent Protection

The programmable range of the overcurrent fault and warning voltage thresholds places a functional limit on the input voltage of the current sense amplifier. The minimum overcurrent fault and warning thresholds correspond to a voltage from CSxP to CSxN of 6 mV and 4.7 mV, respectively. If the voltage across these pins does not exceed the minimum thresholds, then overcurrent fault and warning cannot be tripped, regardless of the setting of IOUT_OC_FAULT_LIMIT and IOUT_OC_WARN_LIMIT. There is also maximum overcurrent fault and warning thresholds corresponding to a voltage from CSxP to CSxN of 60 mV and 59 mV, respectively. If the voltage across these pins exceeds this maximum threshold, the overcurrent fault or warning will be tripped, regardless of the setting of IOUT_OC_FAULT_LIMIT and IOUT_OC_WARN_LIMIT. The result is that for higher values of the setting of IOUT_OC_FAULT_LIMIT and IOUT_OC_WARN_LIMIT. The result is that for higher values of inductor DCR, a resistor across the current sensing capacitor may be required to create a voltage divider into the current sensing inputs.

The device implements cycle-by-cycle current limit when the peak sensed current exceeds the set threshold. In a time constant matched current sensor network, the signal across the CSxP and CSxN pins has both dc and ac inductor current information, so an overcurrent fault trips when the dc current plus half of the ripple current exceeds the set threshold. When the time constant is not well-matched, the dc current which trips the overcurrent changes accordingly.



Feature Description (continued)

When the controller counts three consecutive clock cycles of an overcurrent condition, the high-side and low-side MOSFETs are turned off and the controller enters hiccup mode or latches the output off, depending on the IOUT_OC_FAULT_RESPONSE register. In continuous restart hiccup mode, after seven soft-start cycles, normal switching is attempted. If the overcurrent has cleared, normal operation resumes; otherwise, the sequence repeats.

8.3.7 Current Sharing

See the *Two-Phase Mode Operation* section for more information on current sharing.

8.3.8 Linear Regulators

The device has two on-board linear regulators to provide suitable power for the internal circuitry of the device. These pins, BP3 and BP6 must be properly bypassed in function properly. BP3 needs a minimum of 100 nF connected to AGND and BP6 should have approximately 1 µF of capacitance connected to PGND.

It is permissible to use the external regulator to power other circuits if desired, but ensure that the loads placed on the regulators do not adversely affect operation of the controller. The main consideration is to avoid loads with heavy transient currents that can affect the regulator outputs. Transient voltages on these outputs could result in noisy or erratic operation of the device.

Current limits must also be observed. Shorting the BP3 pin to GND damages the BP3 regulator. The BP3 regulator input comes from the BP6 regulator output. The BP6 regulator can supply 120 mA so the total current drawn from both regulators must be less than that. This total current includes the device operating current I_{VDD} plus the gate drive current required to drive the power FETs. The total available current from two regulators is described in Equation 3 and Equation 4:

$$I_{L(in)} = I_{BP6} - (I_{VDD} + I_{GATE})$$
$$I_{GATE} = f_{SW} \times (Q_{gHIGH} + Q_{gLOW})$$

where

- $I_{L(in)}$ is the total current that can be drawn from BP3 and BP6 in aggregate
- I_{BP6} is the current limit of the BP6 regulator (120-mA minimum)
- I_{VDD} is the quiescent current of the (15-mA maximum)
- I_{GATE} is the gate drive current required by the power FETs
- f_{SW} is the switching frequency
- Q_{qHIGH} is the total gate charge required by the high-side FETs
- Q_{aLOW} is the total gate charge required by the low-side FETs

(4)

(3)

8.3.9 BP Switch-over

If the voltage on the BPEXT pin is lower than the switch-over voltage, $V_{BPEXT(swover)}$, then the internal BP6 regulator is used. If the voltage on the BPEXT pin exceeds this switch-over voltage, then the internal BP6 regulator is bypassed and the BP6 pin follows BPEXT, until the voltage on the BPEXT pin falls by the BPEXT switch-over hysteresis amount, $V_{HYS(swover)}$.

If the BPEXT function is not used, it is recommended to connect the BPEXT pin to GND via a 10 k Ω resistor to increase noise immunity.

Feature Description (continued)

8.3.10 Switching Frequency Setting

The switching frequency is set by the value of the resistor connected from the RT pin to AGND. The RT resistor value is calculated in Equation 5.

$$R_{RT} = \frac{20 \times 10^9}{f_{SW}}$$

where

- R_{RT} is the the resistor from RT pin to AGND, in Ω
- f_{sw} is the desired switching frequency, in Hz

(5)

When the device is synchronized to an external clock, the external clock frequency should be two times the free running frequency that is set by RT resistor. The variation of the external clock frequency should be within $\pm 20\%$, and the switching frequency is one half of the actual clock frequency.

8.3.11 Switching Node and BOOT Voltage

The maximum voltage rating of the switching node and BOOT pins is 30 V. The limit of 30 V on the BOOT1 and BOOT2 pin voltage should be strictly enforced. If the voltage spike of BOOT1 or BOOT2 is above 30 V during operation, the internal boot diode might be damaged and result in permanent failure. To reduce the voltage spike on the switching node, the R-C snubber can be added. Furthermore, the BOOT resistor can be added to slow down the turn-on of high-side switch. If the voltage spike remains above 30 V with an R-C snubber and a boot resistor, add a gate resistor as shown in Figure 13 to slow down the turn-on time of the high-side switch and to further reduce voltage spikes. To eliminate the impact of the gate resistor to the turn-off time of the high-side switch, place a Schottky diode in parallel with the gate resistor.

If the approaches described in this section do not reduce the BOOTx voltage to within 30 V, add an external BOOT diode between the BP6 pin and the BOOTx pin. The forward voltage of the external BOOT diode must be less than that of internal BOOT diode and the voltage rating should be higher than the BOOT voltage spike.



Figure 13. Adding a BOOT Resistor and Gate Resistor

8.3.12 Reading the Output Current

the READ_IOUT command reads the average output current of the device. The results of this command support only positive current or current sourced from the converter. When the converter is sinking current, the result of this command is a reading of 0 A.



Feature Description (continued)

8.3.13 Soft-Start Time

The device supports several soft-start times between 600 μ s and 9 ms. Use the TON_RISE PMBus command to select the soft-start time. See the TON_RISE (61h) command description for full details on the levels and implementation. When selecting the soft-start time, carefully consider the charging current for the output capacitors. In some applications (for example, those with large amounts of output capacitance) this current level can lead to problems with nuisance tripping of the overcurrent protection circuitry. To ensure that this does not happen, include a consideration of the the output capacitor charging current when choosing the overcurrent threshold setting. Use Equation 6 to calculate the output capacitor charging current.

$$I_{CAP} = \left(\frac{\left(V_{OUT} \times C_{OUT}\right)}{t_{SS}}\right)$$

where

- I_{CAP} is the startup charging current of the output capacitance in A
- V_{OUT} is the output voltage of the converter in V
- C_{OUT} is the total output capacitance in F
- t_{SS} is the selected soft-start time in seconds

(6)

After calculating the charging current, the overcurrent threshold can then be calibrated to the sum of the maximum load current and the output capacitor charging current plus some margin. The amount of margin required depends on the individual application, but 25% is a suggested starting point. Individual applications may require more or less than 25%.

8.3.14 Turn-On/Turn-Off Delay and Sequencing

The device provides many sequencing options. Using the ON_OFF_CONFIG command, each rail can be configured to start up whenever the input is not in undervoltage lockout or to additionally require a signal on the CNTLx pin and/or receive an update to the OPERATION command via the PMBus interface.

When the gating signal as specified by ON_OFF_CONFIG is reached for that rail, a programmable turn-on delay can be set with TON_DELAY. The rise time can be programmed with TON_RISE. When the specified signal(s) are set to turn the output off, a programmable turn-off delay set by TOFF_DELAY is used before switching is inhibited. More information can be found in the PMBus command descriptions.

When the output voltage reaches the PGOOD threshold after the start-up period, the PGOOD pin is asserted. This pin can be connected to the CNTL pin of another rail in dual-output mode or on another device to control turn-on and turn-off sequencing.

8.3.15 Pre-Biased Output Start-Up

A circuit in the device prevents current from being pulled from the output during the start-up sequence in a prebiased output condition. There are no PWM pulses until the internal soft-start voltage rises above the error amplifier input (FBx pin), if the output is pre-biased. As soon as the soft-start voltage exceeds the error amplifier input, the device slowly initiates synchronous rectification by starting the synchronous rectifier with a narrow ontime. It then increments that on-time on a cycle-by-cycle basis until it coincides with the time dictated by (1-D), where D is the duty cycle of the converter. This approach prevents the sinking of current from a pre-biased output, and ensures the output voltage start-up and ramp-to-regulation sequences are smooth and controlled.

DESIGN NOTE

During the soft-start sequence, when the PWM pulse width is shorter than the minimum controllable on-time, which is generally caused by the PWM comparator and gate driver delays, pulse skipping may occur and the output might show larger ripple voltage.



Feature Description (continued)

8.3.16 Undervoltage Lockout

The device provides flexible user adjustment of the undervoltage lockout threshold and the hysteresis. Two PMBus commands VIN_ON and VIN_OFF allow the user to set these input voltage turn on and turn off thresholds independently, with a minimum of 4-V turn off to a maximum 16-V turn on. See the individual command descriptions for more details.

8.3.17 Overvoltage and Undervoltage Fault Protection

The device has output overvoltage protection and undervoltage protection capability. The comparators that regulate the overvoltage and undervoltage conditions use the FBx pin as the output sensing point so the filtering effect of the compensation network connected from COMPx to FBx has an effect on the speed of detection. As the output voltage rises or falls below the nominal value, the error amplifier attempts to force FBx to match its reference voltage. When the error amplifier is no longer able to do this, the FB pin begins to drift and trip the overvoltage threshold (V_{OVP}) or the undervoltage threshold (V_{UVP}).

When an undervoltage fault is detected, the device enters hiccup mode and resumes normal operation when the fault is cleared.

When an overvoltage fault is detected, the device turns off the high-side MOSFET and latches on the low-side MOSFET to discharge the output current to the regulation level (within the power good window). After the output voltage comes into PG window, the controller resumes normal operation. If the OV condition still exists, the above procedure repeats.

When operating in dual-channel mode, both channels have identical but independent protection schemes which means one channel would not be affected when the other channel is in fault mode.

When operating in two-phase mode, only the FB1 pin is detected for overvoltage and undervoltage fault. Therefore both channels take action together during a fault.

8.3.18 Power Good

User-selectable, power good thresholds determine at what voltage the PGOOD pin is allowed to go high and the associated PMBus flags are cleared. There are three possible settings that can be had. See the POWER_GOOD_ON and POWER_GOOD_OFF command descriptions for complete details. These commands establish symmetrical values above and below the nominal voltage. Values entered for each threshold should be the voltages corresponding to the threshold below the nominal output voltage. For instance, if the nominal output voltage is 3.3 V, and the desired power good on thresholds are ±5%, the POWER_GOOD_ON command is issued with 2.85 V as the desired threshold. The POWER_GOOD_OFF command must be set to a lower value (higher percentage) than the POWER_GOOD_ON command as well.

The FB pin senses the output voltage for the purposes of power good detection. This sensing results in the inherent filtering action provided by the compensation network connected from the COMP pin to the FB pin. As the output voltage rises or falls below the nominal value, the error amplifier attempts to force the FB pin to match its reference voltage. When the error amplifier is no longer able to do this, the FB pin begins to drift and trip the power good threshold. For this reason the network from the COMP pin to the FB pin should have no purely resistive path.

Power good de-asserts during all startups, after any fault condition is detected or whenever the device is turned off or in a disabled state (OPERATION command or CNTLx pins put the device into a disabled or off state). The PGOOD pin acts as a diode to GND when the device has no power applied to the VDD pin.

8.3.19 Overtemperature Fault Protection

The device uses measurements from the external temperature sensors connected on the TSNSx pins for each rail to provide programmable over-temperature fault and warning thresholds. See the *OT_FAULT_LIMIT (4Fh)* and *OT_WARN_LIMIT (51h)* sections for more information about the command descriptions.

8.3.20 Thermal Shutdown

If the junction temperature of the device reaches the thermal shutdown limit of 150°C, the PWMs and the oscillators are turned off and HDRVs and LDRVs are driven low. When the junction cools to the required level (130°C typical), the PWM initiates soft start as during a normal power-up cycle.



Feature Description (continued)

8.3.21 Programmable Fault Responses

The IOUT_OC_FAULT_RESPONSE command programs the overcurrent and output undervoltage response. See the *IOUT_OC_FAULT_RESPONSE (47h)* section for more information about this command description.

8.3.22 User Data

The MFR_SPECIFIC_00 command functions as a scratchpad to store 16 bits of arbitrary data. These bits can represent any information that the application requires and can be stored in EEPROM for non-volatility.

8.3.23 Adjustable Anti-Cross Conduction Delay

The MFR_SPECIFIC_21 command allows provides two anti-cross conduction delay (dead-time) options for each channel. Bit 0 of this command selects between two dead-time settings for channel 1, and bit 1 of this command selects between two dead-time settings for channel 2. In each case, writing this bit to a 1 selects the longer dead-time option. The particular option required for a given application depends upon several things such as FET total gate charge, FET gate resistance, PCB layout quality, and temperature. The proper setting for a given design is highly application-dependent, however, for FETs above 25-nC gate charge, the longer dead-time setting is generally considered. The shorter dead-time setting allows for higher efficiency in applications where FETs are generally small and switch very quickly. In applications with larger and slower switching FETs, a shorter dead-time leads to small amounts of cross conduction. Conversely, using the longer dead-time settings with smaller, faster switching FETs leads to excessive body diode conduction in the low-side FET, leading to a drop in overall converter efficiency.

8.3.24 Connection of Unused Pins

In some case, it is possible that some pins are not used. For example, if only channel 1 is used, then pins for channel 2 needs to be properly connected as well. The unused pin connections are summarized in Table 1.

PIN NAME	CONNECTION
BOOTx	Floating
BPEXT	Connect to ground
CLK	Pull up to BP3 via 100-kΩ resistor
CNTLx	Connect to ground or high logic level whichever turns PWM off
COMPx	Floating
CSxN	Connect to ground
CSxP	Connect to ground
DATA	Pull up to BP3 via 100-k Ω resistor
DIFFO1	Floating
FBx	Connect to ground
GSNSx	Connect to ground
HDRVx	Floating
LDRVx	Floating
PGx	Connect to ground
SMBALERT	Pull up to BP3 via 100-k Ω resistor
SWx	Connect to ground
SYNC	Connect to ground
TSNSx	Floating
VSNSx	Connect to ground is recommended. Connect to output voltage is also allowed.

Table 1. Unused Pin Connections



8.4 Device Functional Modes

8.4.1 Control Signal

The value in the ON_OFF_CONFIG register commands the device to use the control pin to enable or disable regulation, regardless of the state of the OPERATION command. The minimum input high threshold for the control signal is 2.1 V, and the maximum input low threshold for the control pin is 0.8 V. The control pin can be configured as either active high or active low logic.

8.4.2 **OPERATION Command**

The value in the ON_OFF_CONFIG register, commands the device to use the OPERATION command to enable or disable regulation, regardless of the state of the control signal.

8.4.3 Control Signal and OPERATION Command

The value in the ON_OFF_CONFIG register commands the device to require both control signal and the OPERATION command to enable or disable regulation.

8.4.4 Two-Phase Mode Operation

The device can be configured to operate in single-output two-phase mode for high-current applications. With proper selection of the external MOSFETs, this device can support up to 50-A of load current in a two-phase configuration. Figure 14 shows the device configured for two-phase mode with the FB2 pin tied to the BP6 pin. In this mode, COMP1 must be connected to COMP2 to ensure current sharing between the two phases. For high-current applications, the remote sense amplifier compensates for the parasitic offset to provide an accurate output voltage. The DIFFO1 pin, the output of the remote sensing amplifier, is connected to the resistor divider of the feedback network.



Figure 14. Connections in a Two-Phase Mode Configuration

Table 2 summaries the channel 2 related pin connection in two-phase mode. Figure 15 shows a typical a two-phase mode application using the device.





Figure 15. Using the in a Two-Phase Mode Application

TEXAS INSTRUMENTS

www.ti.com.cn

PIN NAME	CONNECTION
CNTL2	Floating or connect to ground
COMP2	Connect to COMP1
FB2	Connect to BP6
GSNS2	Connect to ground
PG2	Floating or connect to ground
VSNS2	Connect to ground is recommended. Connect to output voltage is also allowed.

Table 2. Channel 2 Pin Connections in Two-Phase Mode

When the device operates in two-phase mode, a current sharing loop as shown in Figure 16 is designed to maintain the current balance between phases. Both phases share the same comparator voltage (COMP1). The sensed current in each phase is compared first in a current share block, then compared to an error current and then fed into the COMP pin. The resulting error voltage is compared with the voltage ramp to generate the PWM pulse.



Figure 16. Two-Phase Mode Current Share Loop



8.5 Programming

8.5.1 Supported PMBus Commands

8.5.1.1 PMBus Address

The PMBus protocol specification requires that each device connected to the PMBus interface have a unique address on the bus. The device has 64 possible addresses (0 through 63 in decimal) that can be assigned by connecting resistors from the ADDR0 and ADDR1 pins to AGND. The device sets the address in the form of two octal (0-7) digits, one digit for each pin. The ADDR1 pin is the high-order digit and the ADDR0 pin is the low-order digit.

The E48 series resistors suggested for each digit value are shown in Table 3.

DIGIT	RESISTANCE (kΩ)
0	11
1	18.7
2	27.4
3	38.3
4	53.6
5	82.5
6	127
7	187

Table	3.	E48	Series	Resistors
-------	----	-----	--------	-----------

The device also detects values that are out of range on the ADDR0 and ADDR1 pins. If either pin is detected as having an out of range resistance connected to it, the device continues to respond to PMBus commands, but at address 127, which is outside of the possible programmed addresses. It is possible but not recommended to use the device in this condition, especially if other devices are present on the bus or if another device could possibly occupy the 127 address.

8.5.1.2 PMBus Connections

The device supports both 100-kHz and 400-kHz bus speeds. Connection for the PMBus interface should follow the *High Power DC* specifications given in section 3.1.3 on the System Management Bus (SMBus) Specification V2.0 for the 400-kHz bus speed or the *Low Power DC* specifications in section 3.1.2. The complete SMBus specification is available from the SMBus web site, smbus.org.

8.5.1.3 PMBus Data Format

There are three data formats supported in the PMBus protocol commands that require representation of a literal number as their argument (commands that set thresholds, voltages or report such). A compatible device needs to support only one of these formats. The device supports the *Linear* data format only for these commands. In this format, the data argument consists of two parts, a mantissa and an exponent. The number represented by this argument can be expressed as shown in Equation 7.

Value = Mantissa
$$\times 2^{exponent}$$

(7)

ZHCS614F-OCTOBER 2011-REVISED JANUARY 2017

8.5.1.4 PMBus Interface Output Voltage Adjustment

The nominal output voltage of the converter can be adjusted using the VREF_TRIM command. See the VREF_TRIM command description for the format of this command as used in the device. The adjustment range is between -20% and +10% from the nominal output voltage. The VREF_TRIM command is typically used to trim the final output voltage of the converter without relying on high precision resistors being used in Figure 9. The resolution of the adjustment is 2 mV. The combination of margining and VREF_TRIM is limited to the range between -30% and +10% from the nominal output voltage. Exceeding this range is not supported.

The device operates in three states that determine the actual output voltage:

- No output margin
- Margin high
- Margin low

These output states are set using the OPERATION command. The FB pin reference voltage is calculated as follows in each of these states.

No margin voltage:

$V_{FB} = VREF_TRIM + 0.$	6
---------------------------	---

Margin high voltage state:

 $V_{FB} = STEP VREF MARGIN HIGH + VREF TRIM + 0.6$

Margin low state:

 $V_{FB} = STEP VREF MARGIN LOW + VREF TRIM + 0.6$

where

- V_{FB} is the FB pin voltage
- VREF_TRIM is the offset voltage in volts to be applied to the output voltage
- VREF_MARGIN_HIGH is the requested margin high voltage
- VREF_MARGIN_LOW is the requested margin low voltage

For these conditions, the output voltage is shown in Equation 11.

$$V_{OUT} = V_{FB} \times \left(\frac{(R2 + R1)}{R2}\right)$$

where

- V_{FB} is the pin voltage calculated in Equation 8, Equation 9 or Equation 10 depending on the output state
- R2 and R1 are in consistent units from Figure 9
- V_{OUT} is the output voltage

(11)

(10)

NOTE

The device limits the combination of margining and VREF_TRIM to the range between -30% and +10% of the nominal output voltage. The FB pin voltage can deviate no more that this from the nominal 600 mV.

8.6 Register Maps

The device supports commands from the PMBus 1.1 specification as shown in Table 4.



(8)

(9)



Table 4. PMBus Command Summary

CODE	COMMAND NAME	WORD/BYTE	DESCRIPTION: PMBus Command	USER WRITABLE	FACTORY DEFAULT VALUE
00h	PAGE	Byte	Locates separate PMBus command lists in multiple output environments	Yes	0XXX XXX0
01h	OPERATION	Byte	Turn the unit on and off in conjunction with the input from the CONTROL pin. Set the output voltage to the upper or lower MARGIN VOLTAGES.	Yes	0X00 00XX
02h	ON_OFF_CONFIG	Byte	Configures the combination of CONTROL pin input and serial bus commands needed to turn the unit on and off. This includes how the unit responds when power is applied.	Yes	XXX1 0110
03h	CLEAR_FAULTS	Byte	Clears all fault status registers to 0x00. The "Unit is Off" bit in the status byte is not cleared when this command is issued.	Yes ⁽¹⁾	NONE
10h	WRITE_PROTECT	Byte	Prevents unwanted writes to the device.	Yes	000X XXXX
15h	STORE_USER_ALL	Byte	Saves the current configuration into the User Store. Note: This command writes to Non-Volatile Memory.	Yes ⁽¹⁾	NONE
16h	RESTORE_USER_ALL	Byte	Restores all parameters to the settings saved in the User Store.	Yes ⁽¹⁾	NONE
19h	CAPABILITY	Byte	PEC,SPD,ALRT	No	1011 0000
20h	VOUT_MODE	Byte	Read-Only Mode Indicator. The data format is linear with an exponent of -9	No	0001 0111
35h	VIN_ON	Word	Sets the value of the input voltage at which the unit should start power conversion	Yes	1111 0000 0001 0001
36h	VIN_OFF	Word	Sets the value of the input voltage at which the unit should stop power conversion.	Yes	1111 0000 0001 0000
38h	IOUT_CAL_GAIN	Word	Sets the ratio of the voltage at the current sense pins to the sensed current.	Yes	1000 1000 0001 0000
39h	IOUT_CAL_OFFSET	Word	Nulls any offsets in the output current sensing circuit.	Yes	1110 0000 0000 0000
46h	IOUT_OC_FAULT_LIMIT	Word	Sets the value of the output current, in amperes, that causes the overcurrent detector to indicate an overcurrent fault condition.	Yes	1111 1000 0011 1100
47h	IOUT_OC_FAULT_RESPONSE	Byte	Instructs the device on what action to take in response to an output overcurrent fault.	Yes	0011 1100
4Ah	IOUT_OC_WARN_LIMIT	Word	Sets the value of the output current that casues an output overcurrent warning.	Yes	1111 1000 0011 0110
4Fh	OT_FAULT_LIMIT	Word	Overtemperature Fault Threshold	Yes	0000 0000 1001 0001
5lh	OT_WARN_LIMIT	Word	Overtemperature Warning Threshold	Yes	0000 0000 0111 1101
61h	TON_RISE	Word	Target Soft-Start Rise Time	Yes	1110 0000 0010 1011
78h	STATUS_BYTE	Byte	Single byte status indicator	No	0x00 0000

(1) No data bytes are sent, only the command code is sent.

TPS40422 ZHCS614F – OCTOBER 2011 – REVISED JANUARY 2017

Ų	Texas Instruments
	INSTRUMENTS

www.ti.com.cn

Table 4. PMBus Command Summary (continued)

CODE	COMMAND NAME	WORD/BYTE	DESCRIPTION: PMBus Command	USER WRITABLE	FACTORY DEFAULT VALUE
79h	STATUS_WORD	Word	Full 2-byte status indicator	No	0000 0000 0x00 0000
7Ah	STATUS_VOUT	Byte	Output Voltage Fault Status Detail	No	0000 0000
7Bh	STATUS_IOUT	Byte	Output Current Fault Status Detail	No	0000 0000
7Dh	STATUS_TEMPERATURE	Byte	Temperature Fault Status Detail	No	0000 0000
7Eh	STATUS_CML	Byte	Communication, Memory, and Logic Fault Status Detail	No	0000 0000
80h	STATUS_MFR_SPECIFIC	Byte	Manufacturer Specific Fault Status Detail.	No	0000 0000
8Bh	READ_VOUT	Word	Read output voltage	No	0000 0000 0000 0000
8Ch	READ_IOUT	Word	Read output current	No	1110 0000 0000 0000
8Eh	READ_TEMPERATURE_2	Word	Read off-chip temp sensor	No	0000 0000 0001 1001
98h	PMBUS_REVISION	Byte	PMBus Revision Information	No	0001 0001
D0h	MFR_SPECIFIC_00	Word	User scratch pad	Yes	0000 0000 0000 0000
D4h	MFR_SPECIFIC_04	Word	VREF_TRIM	Yes	0000 0000 0000 0000
D5h	MFR_SPECIFIC_05	Word	STEP_VREF_MARGIN_HIGH	Yes	0000 0000 0001 1110
D6h	MFR_SPECIFIC_06	Word	STEP_VREF_MARGIN_LOW	Yes	1111 1111 1110 0010
D7h	MFR_SPECIFIC_07	Byte	PCT_VOUT_FAULT_PG_LIMIT	Yes	0000 0000
D8h	MFR_SPECIFIC_08	Byte	SWQUENCE_TON_TOFF_DELAY	Yes	0000 0000
E5h	MFR_SPECIFIC_21	Word	IC options	Yes	0000 0000 0000 0100
FCh	MFR_SPECIFIC_44	Word	Device Code, Unique Code to ID part number	No	0000 0000 0111 0100



8.6.1 Supported Commands

The device supports the following commands from the PMBus protocol 1.1 specification.

8.6.1.1 PAGE (00h)

The PAGE command provides the ability to configure, control, and monitor both channels (outputs) of the device through only one physical address.

COMMAND		PAGE						
Format				Unsigne	ed binary			
Bit Position	7	6	5	4	3	2	1	0
Access	r/w	r	r	r	r	r	r	r/w
Function	PA	Х	Х	Х	Х	Х	Х	P0
Default Value	0	Х	Х	Х	Х	Х	Х	0

Table 5. PAGE Command Truth Table

PA	P0	LOGIC RESULTS
0	0	All commands address the first channel
0	1	All commands address the second channel
1	0	Illegal input. Ignore this write, take no action
1	1	All commands address both channels

If PAGE = 11, then any read commands only affect the first channel. Any value written to read-only registers is ignored.

8.6.1.2 **OPERATION** (01h)

OPERATION is a paged register. The OPERATION command turns the device output on or off in conjunction with input from the CNTLx pins. It is also used to set the output voltage to the upper or lower MARGIN voltages. The unit stays in the commanded operating mode until a subsequent OPERATION command or a change in the state of the CNTLx pins instructs the device to change to another mode.

COMMAND		OPERATION						
Format		Unsigned binary						
Bit Position	7	6	5	4	3	2	1	0
Access	r/w	r	r/w	r/w	r/w	r/w	r	r
Function	ON	Х		Ма	rgin		Х	Х
Default Value	0	Х	0	0	0	0	Х	Х

8.6.1.2.1 On

This bit is an enable command to the converter.

- 0: output switching is disabled. Both drivers placed in an off or low state.
- 1: output switching is enabled. The device is allowed to begin power conversion assuming no fault conditions exist.

TPS40422 ZHCS614F – OCTOBER 2011 – REVISED JANUARY 2017



8.6.1.2.2 Margin

If Margin Low is enabled, load the value from the VOUT_MARGIN_LOW command. If Margin High is enabled, load the value from the VOUT_MARGIN_HIGH command. (See PMBus specification for more information)

- 00XX: Margin Off
- 0101: Margin Low (Ignore on Fault)
- 0110: Margin Low (Act on Fault)
- 1001: Margin High (Ignore on Fault)
- 1010: Margin High (Act on Fault)

8.6.1.3 ON_OFF_CONFIG (02h)

ON_OFF_CONFIG is a paged register. The ON_OFF_CONFIG command configures the combination of CNTLx pins input and serial bus commands needed to turn the unit on and off. The contents of this register can be stored to non-volatile memory using the STORE_USER_ALL command.

COMMAND		ON_OFF_CONFIG						
Format		Unsigned binary						
Bit Position	7	6	5	4	3	2	1	0
Access	r	r	r	r/w	r/w	r/w	r/w	r
Function	Х	Х	Х	pu	cmd	cpr	pol	сра
Default Value	Х	Х	Х	1	0	1	1	0

8.6.1.3.1 pu

The pu bit sets the default to either operate any time power is present or for the on/off to be controlled by CNTLx pins and PMBus OPERATION command. This bit is used in conjunction with the 'cp', 'cmd', and 'on' bits to determine start up.

Bit Value	ACTION
0	Channel powers up any time power is present regardless of state of the CNTLx pins.
1	Channel does not power up until commanded by the CNTLx pins and OPERATION command as programmed in bits [2:0] of the ON_OFF_CONFIG register.

8.6.1.3.2 cmd

The cmd bit controls how the device responds to the OPERATION command.

Bit Value	ACTION
0	Channel ignores the "on" bit in the OPERATION command.
1	Channel responds to the "on" bit in the OPERATION command.

8.6.1.3.3 cpr

The cpr bit sets the CNTLx pins response. This bit is used in conjunction with the 'cmd', 'pu', and 'on' bits to determine start up.

Bit Value	ACTION
0	Channel ignores the CNTLx pins. On/off is controlled only by the OPERATION command.
1	Channel requires the CNTLx pins to be asserted to start the unit.

8.6.1.3.4 pol

The pol bit controls the polarity of the CNTLx pins. For a change to become effective, the contents of the ON_OFF_CONFIG register must be stored to non-volatile memory using the STORE_USER_ALL command and the device power cycled. Simply writing a new value to this bit does not change the polarity of the CNTLx pins.



Bit Value	ACTION
0	CNTLx pins is active low.
1	CNTLx pins is active high.

8.6.1.3.5 cpa

The cpa bit sets the CNTLx pins action when turning the controller off. This bit is read internally and cannot be modified by the user.

Bit Value	ACTION	
0	Turn off the output using the programmed delay.	

8.6.1.4 CLEAR_FAULTS (03h)

The CLEAR_FAULTS command is used to clear any fault bits that have been set. This command clears all bits in all status <u>registers in</u> the selected page simultaneously. At the <u>same time</u>, the device negates (clears, releases) its SMBALERT signal output if the device is asserting the SMBALERT signal. The CLEAR_FAULTS command does not cause a unit that has latched off for a fault condition to restart. If the fault is still present when the bit is cleared, the fault bit is immediately reset and the host notified by the usual means.

8.6.1.5 WRITE_PROTECT (10h)

The WRITE_PROTECT command is used to control writing to the PMBus interface device. The intent of this command is to provide protection against accidental changes. This command is not intended to provide protection against deliberate or malicious changes to the device configuration or operation. All supported command parameters may have their parameters read, regardless of the WRITE_PROTECT settings. The contents of this register can be stored to non-volatile memory using the STORE_USER_ALL command.

COMMAND	WRITE_PROTECT							
Format		Unsigned binary						
Bit Position	7	6	5	4	3	2	1	0
Access	r/w	r/w	r/w	Х	Х	Х	Х	Х
Function	bit7	bit6	bit5	Х	Х	Х	Х	Х
Default Value	0	0	0	Х	Х	Х	Х	х

8.6.1.5.1 bit5

Bit Value	ACTION
0	Enable all writes as permitted in bit6 or bit7
1	Disable all writes except the WRITE_PROTECT, PAGE, OPERATION and ON_OFF_CONFIG. (bit6 and bit7 must be 0 to be valid data)

8.6.1.5.2 bit6

Bit Value	ACTION
0	Enable all writes as permitted in bit5 or bit7
1	Disable all writes except for the WRITE_PROTECT, PAGE and OPERATION commands. (bit5 and bit7 must be 0 to be valid data)

8.6.1.5.3 bit7

Bit Value	ACTION
0	Enable all writes as permitted in bit5 or bit6
1	Disable all writes except for the WRITE_PROTECT command. (bit5 and bit6 must be 0 to be valid data)



In any case, only one of the three bits may be set at any one time. Attempting to set more than one bit results in an alert being generated and the CML bit in STATUS_WORD being set.

8.6.1.6 STORE_USER_ALL (15h)

The STORE_USER_ALL command stores all of the current storable register settings in the EEPROM memory as the new defaults on power up.

It is permissible to use this command while the device is switching. Note however that the device continues to switch but ignores all fault conditions until the internal store process has completed.

EEPROM programming faults cause the device to NACK and set the 'cml' bit in the STATUS_BYTE and the 'oth' bit in the STATUS_CML registers.

8.6.1.7 RESTORE_USER_ALL (16h)

The RESTORE_USER_ALL command restores all of the storable register settings from EEPROM memory.

This command should not be used while the device is actively switching. If this is done, the device stops switching the output drivers and the output voltage drops. Depending on loading conditions, the output voltage could reach an undervoltage level and trigger an undervoltage fault response if programmed to do so. The command can be used while the device is switching, but it is not recommended as it results in a restart that could disrupt power sequencing requirements in more complex systems. It is strongly recommended that the device be stopped before issuing this command.

8.6.1.8 CAPABILITY (19h)

The CAPABILTY command provides a way for a host system to determine some key capabilities of this PMBus interface device.

COMMAND		CAPABILITY													
Format		Unsigned binary													
Bit Position	7	6	5	4	3	2	1	0							
Access	r	r	r	r	r	r	r	r							
Function	PEC	SI	PD	ALRT	Reserved										
Default Value	1	0	1	1	1 0 0 0										

The default values indicate that the device supports Packet Error Checking (PEC), a maximum bus speed of 400 kHz (SPD) and the SMBus Alert Response Protocol using a SMBALERT pin (ALRT).

8.6.1.9 VOUT_MODE (20h)

The PMBus specification dictates that the data word for the VOUT_MODE command is one byte that consists of a 3-bit mode and 5-bit exponent parameter, as shown below. The 3-bit mode sets whether the device uses the Linear or Direct modes for output voltage related commands. The 5-bit parameter sets the exponent value for the linear data mode. The mode and exponent parameters are set and do not permit the user to change the values.

COMMAND		VOUT_MODE													
Bit Position	7	6	5	4	3	2	1	0							
Access	r	r	r	r	r	r	r	r							
Function		Mode		Exponent											
Default Value	0	0	0	1	0	1	1	1							

8.6.1.9.1 Mode:

Value fixed at 000, linear mode.

8.6.1.9.2 Exponent

Value fixed at 10111, Exponent for Linear mode values is -9.

8.6.1.10 VIN_ON (35h)

The VIN_ON command sets the value of the input voltage at which the unit should start operation assuming all other required startup conditions are met. Values are mapped to the nearest supported increment. Values outside the supported range are treated as invalid data and cause the device set the CML bit in the STATUS_BYTE and the invalid data (ivd) bit in the STATUS_CML registers. The value of VIN_ON remains unchanged on an out-of-range write attempt. The contents of this register can be stored to non-volatile memory using the STORE_USER_ALL command.

The supported VIN_ON values are:

4.25 (default)	4.5	4.75	5	5.25
5.5	5.75	6	6.25	6.5
6.75	7	7.25	7.5	8
8.25	8.5	8.75	9	9.25
9.5	10	10.5	11	11.5
12	12.5	13	14	15
16				

VIN_ON must be set higher than VIN_OFF. Attempting to write either VIN_ON lower than VIN_OFF or VIN_OFF higher than VIN_ON results in the new value being rejected, SMBALERT being asserted along with the CML bit in STATUS_BYTE and the invalid data bit in STATUS_CML.

The data word that accompanies this command is divided into a fixed 5-bit exponent and an 11-bit mantissa. The four most significant bits of the mantissa are fixed, while the lower 7 bits may be altered.

COMMAND		VIN_ON														
Format	Linear, two's complement binary															
Bit Position	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0
Access	r	r	r	r	r	r	r	r	r	r/w						
Function	Exponent					Mantissa										
Default Value	1	1	1	1	0	0	0	0	0	0	0	1	0	0	0	1

8.6.1.10.1 Exponent

-2 (dec), fixed.

8.6.1.10.2 Mantissa

The upper four bits are fixed at 0.

The lower seven bits are programmable with a default value of 17 (dec). This corresponds to a default of 4.25 V.

TPS40422

ZHCS614F-OCTOBER 2011-REVISED JANUARY 2017



8.6.1.11 VIN_OFF (36h)

The VIN_OFF command sets the value of the input voltage at which the unit should stop operation. Values are mapped to the nearest supported increment. Values outside the supported range is treated as invalid data and causes the device to set the CML bit in the STATUS_BYTE and the invalid data (ivd) bit in the STATUS_CML registers. The value of VIN_OFF remains unchanged during an out-of-range write attempt. The contents of this register can be stored to non-volatile memory using the STORE_USER_ALL command.

The supported VIN_OFF values are:

4 (default)	4.25	4.5	4.75	5
5.25	5.5	5.75	6	6.25
6.5	6.75	7	7.25	7.5
8	8.25	8.5	8.75	9
9.25	9.75	10.25	10.75	11.25
11.75	12	13.75	14.75	15.75

VIN_ON must be set higher than VIN_OFF. Attempting to write either VIN_ON lower than VIN_OFF or VIN_OFF higher than VIN_ON results in the new value being rejected, SMBALERT being asserted along with the CML bit in STATUS_BYTE and the invalid data bit in STATUS_CML.

The data word that accompanies this command is divided into a fixed 5 bit exponent and an 11 bit mantissa. The 4 most significant bits of the mantissa are fixed, while the lower 7 bits may be altered.

COMMAND		VIN_OFF														
Format	Linear, two's complement binary															
Bit Position	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0
Access	r	r	r	r	r	r	r	r	r	r/w						
Function	Exponent					Mantissa										
Default Value	1 1 1 1 0 0 0 0 0 0 1 0 0 0										0					

8.6.1.11.1 Exponent

-2 (dec), fixed.

8.6.1.11.2 Mantissa

The upper four bits are fixed at 0.

The lower seven bits are programmable with a default value of 16 (dec). This corresponds to a default value of 4.0 V.

8.6.1.12 IOUT_CAL_GAIN (38h)

IOUT_CAL_GAIN is a paged register. The IOUT_CAL_GAIN is the ratio of the voltage at the current sense element to the sensed current. The units are Ohms (Ω). The effective current sense element can be the DC resistance of the inductor or a separate current sense resistor. The default setting is 0.488 m Ω , and the resolution is 30.5 $\mu\Omega$. The range is 0.244 m Ω to 15.5 m Ω . The contents of this register can be stored to non-volatile memory using the STORE_USER_ALL or STORE_DEFAULT_CODE commands.

COMMAND	IOUT_CAL_GAIN															
Format	Linear, two's complement binary															
Bit Position	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0
Access	r	r	r	r	r	r	r	r/w								
Function	Exponent					Mantissa										
Default Value	1	0	0	0	1	0	0	0	0	0	0	1	0	0	0	0


-15 (dec), fixed.

8.6.1.12.2 Mantissa

The upper two bits are fixed at 0.

The lower nine bits are programmable with a default value of 16 (dec).

Depending on the value of IOUT_CAL_GAIN, the current sense amplifier used for current monitoring (but not overcurrent or current sharing) changes, as shown in Table 6.

	•	•
IOUT_CAL_GAI	N (mΩ) RANGE	
MIN	MAX	CSA GAIN (V/V)
0.244	0.5795	25
0.5796	1.1285	15
1.1286	15.5	10

Table 6. Current Sense Amplifier Settings

8.6.1.13 IOUT_CAL_OFFSET (39h)

IOUT_CAL_OFFSET is a paged register. The IOUT_CAL_OFFSET is used to compensate for offset errors in the READ_IOUT results and the IOUT_OC_FAULT_LIMIT and IOUT_OC_WARN_LIMIT thresholds. The units are amperes. The default setting is 0 A. The resolution of the argument for this command is 62.5 mA and the range is +3937.5 mA to -4000 mA. Values written outside of this range alias into the supported range. For example, 1110 0100 0000 0001 has an expected value of -63.9375 A, but results in 1110 0111 1111 0001 which is -3.9375 A. This occurs because the read-only bits are fixed. The exponent is always -4 and the 5 msb bits of the Mantissa are always equal to the sign bit. The contents of this register can be stored to non-volatile memory using the STORE_USER_ALL command.

COMMAND				IOUT_CAL_OFFSET												
Format						L	inear, t	wo's co	mpleme	nt bina	ry					
Bit Position	7	6 5 4 3 2 1 0 7 6 5 4 3 2 1 0														
Access	r	r r r r r r /w r/w r r r r r r/w r/w r/w										r/w				
Function		E	Exponer	nt		Mantissa										
Default Value	1	1	1	0	0	0	0	0	0	0	0	0	0	0	0	0

8.6.1.13.1 Exponent

-4 (dec), fixed.

8.6.1.13.2 Mantissa

MSB is programmable with sign, next 4 bits are sign extend only. Lower six bits are programmable with a default value of 0 (dec).

TPS40422

ZHCS614F-OCTOBER 2011-REVISED JANUARY 2017



(12)

8.6.1.14 IOUT_OC_FAULT_LIMIT (46h)

IOUT_OC_FAULT_LIMIT is a paged register. The IOUT_OC_FAULT_LIMIT command sets the value of the output current, in amperes, that causes the overcurrent detector to indicate an overcurrent fault condition. The IOUT_OC_FAULT_LIMIT should be set equal to or greater than the IOUT_OC_WARN_LIMIT. Writing a value to IOUT_OC_FAULT_LIMIT less than IOUT_OC_WARN_LIMIT causes the device to set the CML <u>bit in the</u> STATUS_BYTE and the invalid data (ivd) bit in the STATUS_CML registers as well as assert the SMBALRT signal. The contents of this register can be stored to non-volatile memory using the STORE_USER_ALL command.

The IOUT_OC_FAULT_LIMIT takes a two-byte data word formatted as shown below:

COMMAND		IOUT_OC_FAULT_LIMIT														
Format						L	inear, t	wo's cor	npleme	ent binai	У					
Bit Position	7	6 5 4 3 2 1 0 7 6 5 4 3 2 1 0														
Access	r	r	r	r	r	r	r	r	r	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Function		Exponent Mantissa														
Default Value	1	1	1	1	1	0	0	0	0	0	1	1	1	1	0	0

8.6.1.14.1 Exponent

-1 (dec), fixed.

8.6.1.14.2 Mantissa

The upper four bits are fixed at 0.

The lower seven bits are programmable with a default value of 60 (dec).

The actual output current for a given mantissa and exponent is shown in Equation 12.

$$I_{OUT(oc)} = Mantissa \times 2^{Exponent} = \frac{Mantissa}{2}$$

The default output fault current setting is 30 A. Values of $I_{OUT(oc)}$ can range between 3 A and 50 A in 500-mA increments.

8.6.1.15 IOUT_OC_FAULT_RESPONSE (47h)

IOUT_OC_FAULT_RESPONSE is a paged register. The IOUT_OC_FAULT_RESPONSE command instructs the device on what action to take in response to an IOUT_OC_FAULT_LIMIT or an output voltage undervoltage (UV) fault. The device also:

- Sets the IOUT_OC bit in the STATUS_BYTE
- Sets the IOUT/POUT bit in the STATUS_WORD
- Sets the IOUT OC Fault bit in the STATUS_IOUT register
- Notifies the host by asserting SMBALERT

The contents of this register can be stored to non-volatile memory using the STORE_USER_ALL command.

COMMAND			ΙΟυτ	_OC_FAU	LT_RESPO	ONSE					
Format				Unsigne	d binary						
Bit Position	7	7 6 5 4 3 2 1 0									
Access	r	r	r/w	r/w	r/w	r	r	r			
Function	Х	Х	RS[2]	RS[1]	RS[0]	Х	Х	Х			
Default Value	0	0	1	1	1	1	0	0			



8.6.1.15.1 RS[2:0]

- 000: A zero value for the Retry Setting means that the device does not attempt to restart. The output remains disabled until the fault is cleared (See section 10.7 of the PMBus specification.)
- 111: A one value for the Retry Setting means that the device goes through a normal startup (soft-start) continuously, without limitation, until it is commanded off or bias power is removed or another fault condition causes the unit to shutdown.

Any value other than 000 or 111 is not accepted. Attempting to write any other value is rejected, causing the device to assert SMBALERT along with the CML bit in STATUS_BYTE and the invalid data bit in STATUS_CML.

8.6.1.16 IOUT_OC_WARN_LIMIT (4Ah)

IOUT_OC_WARN_LIMIT is a paged register. The IOUT_OC_WARN_LIMIT command sets the value of the output current, in amperes, that causes the over-current detector to indicate an over-current warning. When this current level is exceeded the device:

- Sets the OTHER bit in the STATUS_BYTE
- Sets the IOUT/POUT bit in the STATUS_WORD
- Sets the IOUT overcurrent Warning (OCW) bit in the STATUS_IOUT register, and
- Notifies the host by asserting SMBALRT

The IOUT_OC_WARN_LIMIT threshold should always be set to less than or equal to the IOUT_OC_FAULT_LIMIT. Writing a value to IOUT_OC_WARN_LIMIT greater than IOUT_OC_FAULT_LIMIT causes the device to set the CML bit in the STATUS_BYTE and the invalid data (ivd) bit in the STATUS_CML registers as well as assert the SMBALRT signal. The contents of this register can be stored to non-volatile memory using the STORE_USER_ALL command.

The IOUT_OC_WARN_LIMIT takes a two byte data word formatted as shown below:

COMMAND							ΙΟυΤ	_OC_V	VARN_I	LIMIT						
Format						L	inear, t	wo's co	mpleme	ent binar	У					
Bit Position	7	6 5 4 3 2 1 0 7 6 5 4 3 2 1 0														
Access	r	r r r r r r r r r r r r r/w r/w r/w r/w														
Function		E	Exponer	nt		Mantissa										
Default Value	1	1	1	1	1	0	0	0	0	0	1	1	0	1	1	0

8.6.1.16.1 Exponent

-1 (dec), fixed.

8.6.1.16.2 Mantissa

The upper four bits are fixed at 0.

Lower seven bits are programmable with a default value of 54 (dec).

The actual output warning current level for a given mantissa and exponent is:

$$I_{OUT(OCW)} = Mantissa \times 2^{Exponent} = \frac{Mantissa}{2}$$
 (13)

The default output warning current setting is 27 A. Values of $I_{OUT(OCW)}$ can range from 2 A to 49 A in 500-mA increments.



8.6.1.17 OT_FAULT_LIMIT (4Fh)

OT_FAULT_LIMIT is a paged register. The OT_FAULT_LIMIT command sets the value of the temperature, in degrees Celsius, that causes an over-temperature fault condition, when the sensed temperature from the external sensor exceeds this limit. Upon triggering the over-temperature fault, the following actions are taken:

- Sets the TEMPERATURE bit in the STATUS_BYTE
- Sets the OT Fault bit in the STATUS_TEMPERATURE
- Notifies the host by asserting SMBALERT

Once the over-temperature fault is tripped, the output is latched off until the external sensed temperature falls 20°C below the OT_FAULT_LIMIT, at which point the output goes through a normal startup (soft-start).

The OT_FAULT_LIMIT must always be greater than the OT_WARN_LIMIT. Writing a value to OT_FAULT_LIMIT less than or equal to OT_WARN_LIMIT causes the device to set the CML bit in the STATUS_BYTE and the invalid data (ivd) bit in the STATUS_CML registers as well as asserts the SMBALERT signal. The contents of this register can be stored to non-volatile memory using the STORE_USER_ALL command.

The OT_FAULT_LIMIT takes a two byte data word formatted as shown below.

COMMAND							0	T_FAU	LT_LIM	IT							
Format							I	Unsigne	d binar	у							
Bit Position	7	6 5 4 3 2 1 0 7 6 5 4 3 2 1 0															
Access	r	r r r r r r r r r r r r r r/w r/w r/w r/															
Function		Exponent								Exponent Mantissa							
Default Value	0	0	0	0	0	0	0	0	1	0	0	1	0	0	0	1	

8.6.1.17.1 Exponent

0 (dec), fixed.

8.6.1.17.2 Mantissa

The upper three bits are fixed at 0.

Lower eight bits are programmable with a default value of 145 (dec).

The default over-temperature fault setting is 145°C. Values can range from 120°C to 165°C in 1°C increments.

8.6.1.18 OT_WARN_LIMIT (51h)

OT_WARN_LIMIT is a paged register. The OT_ WARN _LIMIT command sets the value of the temperature, in degrees Celsius, that causes an over-temperature warning condition, when the sensed temperature from the external sensor exceeds this limit. Upon triggering the over-temperature warning, the following actions are taken:

- Sets the TEMPERATURE bit in the STATUS_BYTE
- Sets the OT Warning bit in the STATUS_TEMPERATURE
- Notifies the host by asserting SMBALERT

Once the over-temperature warning is tripped, warning is latched until the external sensed temperature falls 20°C below the OT_WARN_LIMIT.

The OT_WARN_LIMIT must always be less than the OT_FAULT_LIMIT. Writing a value to OT_WARN_LIMIT greater than or equal to OT_FAULT_LIMIT causes the device to set the <u>CML bit in the STATUS_BYTE</u> and the invalid data (ivd) bit in the STATUS_CML registers as well as assert the <u>SMBALERT</u> signal. The contents of this register can be stored to non-volatile memory using the STORE_USER_ALL command.



The OT_WARN_LIMIT takes a two byte data word formatted as shown below:

COMMAND							0	T_WAF	RN_LIM	IT						
Format							I	Unsigne	d binar	y						
Bit Position	7	6 5 4 3 2 1 0 7 6 5 4 3 2 1 0														
Access	r	r r r r r r r r r r r r r r/w r/w r/w r/										r/w				
Function		E	Exponer	nt		Mantissa										
Default Value	0	0	0	0	0	0	0	0	0	1	1	1	1	1	0	1

8.6.1.18.1 Exponent

0 (dec), fixed.

8.6.1.18.2 Mantissa

The upper three bits are fixed at 0.

Lower eight bits are programmable with a default value of 125 (dec).

The default over-temperature fault setting is 125°C. Values can range from 100°C to 140°C in 1°C increments.

8.6.1.19 TON_RISE (61h)

TON_RISE is a paged register. The TON_RISE command sets the time in milliseconds, from when the output starts to rise until the voltage has entered the regulation band. It also determines the rate of the transition of the reference voltage (either due to VREF_TRIM or STEP_VREF_MARGIN_x commands) when this transition is executed during the soft-start period. There are several discrete settings that this command supports. Commanding a value other than one of these values results in the nearest supported value being selected.

The supported TON_RISE times via the PMBus interface are:

- 600 µs
- 900 µs
- 1.2 ms
- 1.8 ms
- 2.7 ms (default value)
- 4.2 ms
- 6.0 ms
- 9.0 ms

A value of 0 ms instructs the unit to bring its output voltage to the programmed regulation value as quickly as possible. The contents of this register can be stored to non-volatile memory using the STORE_USER_ALL command.

The TON_RISE command is formatted as a linear mode two's complement binary integer.

COMMAND									TON_RI	SE						
Format							Line	ear, two	o's comp	lement b	inary					
Bit Position	7	6 5 4 3 2 1 0 7 6 5 4 3 2 1 0														
Access	r	r	r	r	r	r	r	r	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Function		Exponent Mantissa														
Default Value	1	1 1 0 0 0 0 0 0 1 0 1 0 1 1														

8.6.1.19.1 Exponent

-4 (dec), fixed.

8.6.1.19.2 Mantissa

The upper two bits are fixed at 0.

The lower eight bits are programmable with a default value of 43 (dec).



TPS40422

ZHCS614F-OCTOBER 2011-REVISED JANUARY 2017

www.ti.com.cn

8.6.1.20 STATUS_BYTE (78h)

STATUS_BYTE is a paged register. The STATUS_BYTE command returns one byte of information with a summary of the most critical device faults. Three fault bits are flagged in this particular command: output overvoltage, output overcurrent, and over-temperature. The STATUS_BYTE reports communication faults in the CML bit. Other communication faults set the NONE OF THE ABOVE bit.

COMMAND					STATUS	BYTE		
Format					Unsigned	binary		
Bit Position	7	6	5	4	3	2	1	0
Access	r	r	r	r	r	r	r	r
Function	Х	OFF	VOUT_OV	IOUT_OC	VIN_UV	TEMPERATURE	CML	NONE OF THE ABOVE
Default Value	0	х	0	0	0	0	0	0

A "1" in any of these bit positions indicates that:

OFF:

The device is not providing power to the output, regardless of the reason. In device , this flag means that the converter is not enabled.

VOUT_OV:

An output overvoltage fault has occurred.

IOUT_OC:

An output over current fault has occurred.

VIN_UV:

An input undervoltage fault has occurred.

TEMPERATURE:

A temperature fault or warning has occurred.

CML:

A Communications, Memory or Logic fault has occurred.

NONE OF THE ABOVE:

A fault or warning not listed in bit1 through bits 1-7 has occurred, for example an undervoltage condition or an over current warning condition

8.6.1.21 STATUS_WORD (79h)

STATUS_WORD is a paged register. The STATUS_WORD command returns two bytes of information with a summary of the device's fault/warning conditions. The low byte is identical to the STATUS_BYTE above. The additional byte reports the warning conditions for output overvoltage and overcurrent, as well as the power good status of the converter.

COMMAND				ST	TATUS_WOR	RD (low byte)		
Format					Unsigne	d binary		
Bit Position	7	6	5	4	3	2	1	0
Access	r	r	r	r	r	r	r	r
Function	Х	OFF	VOUT_OV	IOUT_OC	VIN_UV	TEMPERATURE	CML	NONE OF THE ABOVE
Default Value	0	х	0	0	0	0	0	0



A "1" in any of the low byte (STATUS_BYTE) bit positions indicates that:

OFF:

The device is not providing power to the output, regardless of the reason. In device , this flag means that the converter is not enabled.

VOUT_OV:

An output overvoltage fault has occurred.

IOUT_OC:

An output over current fault has occurred.

VIN_UV:

An input undervoltage fault has occurred.

TEMPERATURE:

A temperature fault or warning has occurred.

CML:

A Communications, Memory or Logic fault has occurred.

NONE OF THE ABOVE:

A fault or warning not listed in bits 1-7 has occurred

COMMAND				ST	ATUS_WORD (high byte)							
Format					Unsigned binary							
Bit Position	7	7 6 5 4 3 2 1 0										
Access	r	r	r	r	r	r	r	r				
Function	VOUT	IOUT/POUT	Х	MFR	POWER_GOOD	Х	Х	Х				
Default Value	0	0	0	0	0	0	0	0				

A "1" in any of the high byte bit positions indicates that:

VOUT:

An output voltage fault or warning has occurred

IOUT/POUT:

An output current warning or fault has occurred. The PMBus specification states that this also applies to output power. device does not support output power warnings or faults.

MFR:

An internal thermal shutdown (TSD) fault has occurred in the device.

POWER_GOOD:

The power good signal has not transitioned from high-to-low. This is not implemented in two-phase operation.

8.6.1.22 STATUS_VOUT (7Ah)

STATUS_VOUT is a paged register. The STATUS_VOUT command returns one byte of information relating to the status of the converter's output voltage related faults. The only bits of this register supported are:

- VOUT_OV Fault
- VOUT_UV Fault

COMMAND	STATUS_VOUT
Format	Unsigned binary



TPS40422

ZHCS614F-OCTOBER 2011-REVISED JANUARY 2017

www.ti.com.cn

COMMAND				STATUS_VO	UT			
Bit Position	7	6	5	4	3	2	1	0
Access	r	r	r	r	r	r	r	r
Function	VOUT OV Fault	Х	Х	VOUT UV Fault	Х	Х	Х	Х
Default Value	0	0	0	0	0	0	0	0

A "1" in any of these bit positions indicates that:

VOUT OV Fault:

The device has seen the output voltage rise above the output overvoltage threshold.

VOUT UV Fault:

The device has seen the output voltage fall below the output undervoltage threshold.

8.6.1.23 STATUS_IOUT (7Bh)

STATUS_IOUT is a paged register. The STATUS_IOUT command returns one byte of information relating to the status of the converter's output current related faults. The only bits of this register supported are .

- IOUT_OC Fault
- IOUT_OC Warning

COMMAND				STATUS_IO	UT										
Format				Unsigned bin	ary										
Bit Position	7	7 6 5 4 3 2 1 0													
Access	r	/ 0 5 4 3 2 1 0 r													
Function	IOUT_OV Fault	Х	IOUT OC Warning	Х	Х	Х	Х	Х							
Default Value	0	O O													

A "1" in any of these bit positions indicates that:

IOUT_OV Fault:

The device has seen the output current rise above the level set by IOUT_OC_FAULT_LIMIT.

VOUT_UV Fault:

The device has seen the output current rise relating to the level set by IOUT_OC_WARN_LIMIT.

8.6.1.24 STATUS_TEMPERATURE (7Dh)

STATUS_TEMPERATURE is a paged register. The STATUS_TEMPERATURE command returns one byte of information relating to the status of the external temperature related faults. The only bits of this register supported are:

- OT Fault
- OT Warning

COMMAND			ST	ATUS_TEM	PERATURE									
Format				Unsigned	binary									
Bit Position	7	7 6 5 4 3 2 1 0												
Access	r	1 2 3 2 3 1 <th1< th=""> <th1< th=""> <th1< th=""> <th1< th=""></th1<></th1<></th1<></th1<>												
Function	OT Fault	OT Warning	Х	Х	Х	Х	Х	Х						
Default Value	0	0	0	0	0	0	0	0						

A "1" in any of these bit positions indicates that:

OT Fault:

The measured external temperature has exceeded the level set by OT_FAULT_LIMIT.



OT Warning:

The measured external temperature has exceeded the level set by OT_WARN_LIMIT.

8.6.1.25 STATUS_CML (7Eh)

The STATUS_CML command returns one byte of information relating to the status of the converter's communication related faults. The bits of this register supported by the device are:

- Invalid/Unsupported Command
- Invalid/Unsupported Data
- Packet Error Check Failed
- Memory Fault Detected
- Other Communication Fault.

COMMAND			STA	TUS_CML								
Format			Unsig	ned binary								
Bit Position	7 6 5 4 3 2 1											
Access	r	r	r	r	r	r	r	r				
Function	Invalid/ Unsuppported Command	Invalid/ Unsupported Data	Packet Error Check Failed	Memory Fault Detected	х	х	Other Communication Fault	х				
Default Value	0	0	0	0	0	0	0	0				

A "1" in any of these bit positions indicates that:

Invalid/Unsupported Command:

An invalid or unsupported command has been received.

Invalild/Unsupported Data

Invalid or unsupported data has been received

Packet Error Check Failed

A packet has failed the CRC error check.

Memory Fault Detected

A fault has been detected with the internal memory.

Other Communication Fault

Some other communication fault or error has occurred

TPS40422 ZHCS614F – OCTOBER 2011 – REVISED JANUARY 2017

8.6.1.26 STATUS_MFR_SPECIFIC (80h)

The STATUS_MFR_SPECIFIC command returns one byte of information relating to the status of manufacturerspecific faults or warnings.

COMMAND			STATUS_	MFR_SPECIFIC											
Format			Unsig	gned binary											
Bit Position	7	7 6 5 4 3 2 1 0													
Access	r	r	r	r	r	r	r	r							
Function	OTFI	Х	Х	IVADDR	Х	Х	Х	TWOPH_EN							
Default Value	0	0	0	0	0	0	0	0							

A "1" in any of these bit positions indicates that:

OTFI:

The internal temperature is above the thermal shutdown (TSD) fault threshold

IVADDR:

The PMBus address detection circuit is not resolving to a valid address. In this event, the device responds to the address 127 (dec).

TWOPH_EN:

The part has detected that it is in two-phase mode (by pulling FB2 high). This bit does not trigger SMBALERT.

8.6.1.27 READ_VOUT (8Bh)

READ_VOUT is a paged register. The READ_VOUT commands returns two bytes of data in the linear data format that represent the output voltage of the controller. The output voltage is sensed at the remote sense amplifier output pin so voltage drop to the load is not accounted for. The data format is as shown below:

COMMAND								F	READ_V	JUT						
Format							Lin	ear, two	o's comp	lement b	inary					
Bit Position	7	7 6 5 4 3 2 1 0 7 6 5 4 3 2 1 0													0	
Access	1 1 2 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1													r		
Function									Mantiss	sa						
Default Value	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

The setting of the VOUT_MODE affects the results of this command as well. In the device, VOUT_MODE is set to linear mode with an exponent of -9 and cannot be altered. The output voltage calculation is shown in Equation 14.

 $V_{OUT} = Mantissa \times 2^{Exponent}$

(14)



8.6.1.28 READ_IOUT (8Ch)

READ_IOUT is a paged register. The READ_IOUT commands returns two bytes of data in the linear data format that represent the output current of the controller. The output current is sensed across the CSxP and CSxN pins. The data format is as shown below:

COMMAND								F	READ_IC	UT						
Format							Line	ear, two	o's comp	ement b	inary					
Bit Position	7	7 6 5 4 3 2 1 0 7 6 5 4 3 2 1 0														
Access	r	r	r	r	r	r	r	r	r	r	r	r	r	r	r	r
Function	Exponent Mantissa															
Default Value	Exponent Mantissa 1 1 0												0			

The output current is scaled before it reaches the internal analog to digital converter so that resolution of the output current read is 62.5 mA. The IOUT_CAL_GAIN and IOUT_CAL_OFFSET parameters must be set correctly in order to obtain accurate results. The output current can be found by using Equation 15.

 $I_{OUT} = Mantissa \times 2^{Exponent}$

(15)

8.6.1.28.1 Exponent

Fixed at -4.

8.6.1.28.2 Mantissa

The lower 10 bits are the result of the ADC conversion of the input voltage. The 11th bit is fixed at 0 because only positive numbers are considered valid. Any computed negative current is reported as 0 A..

8.6.1.29 READ_TEMPERATURE_2 (8Eh)

READ_TEMPERATURE_2 is a paged register. The READ_TEMPERATURE_2 command returns the external temperature in degrees Celsius of the current channel.

COMMAND							F	READ_	TEMPE	RATURE	_2					
Format							Line	ear, two	o's comp	lement b	inary					
Bit Position	7	7 6 5 4 3 2 1 0 7 6 5 4 3 2 1 0														0
Access	r	1 1 2 1 0 1 0 3 4 3 2 1 1 1 1 1 1 1 1 1 1 1 1														
Function	Exponent Mantissa															
Default Value	Exponent Mantissa 0 0 0 0 0 0 0 1 1 0 0 1													1		

8.6.1.29.1 Exponent

0 (dec), fixed.

8.6.1.29.2 Mantissa

The lower 11 bits are the result of the ADC conversion of the external temperature. The default reading is 25 (dec) corresponding to a temperature of 25°C.



ZHCS614F-OCTOBER 2011-REVISED JANUARY 2017

8.6.1.30 PMBUS_REVISION (98h)

The PMBUS_REVISION command returns a single, unsigned binary byte that indicates that the device is compatible with the 1.1 revision of the PMBus protocol specification.

COMMAND				PMBUS_	REVISION										
Format		Unsigned binary													
Bit Position	7	7 6 5 4 3 2 1 0													
Access	r	r	r												
Default Value	0	0 0 0 1 0 0 1													

8.6.1.31 MFR_SPECIFIC_00 (D0h)

The MFR_SPECIFIC_00 register is dedicated as a user scratch pad.

COMMAND								MFR	SPECI	FIC_00						
Format								Ur	nsigned b	binary						
Bit Position	7	7 6 5 4 3 2 1 0 7 6 5 4 3 2 1 0														0
Access	r/w	r/w r/w														
Function								Us	er scrato	h pad						
Default Value	0 0															

The contents of this register can be stored to non-volatile memory using the STORE_USER_ALL command.

8.6.1.32 VREF_TRIM (MFR_SPECIFIC_04) (D4h)

VREF_TRIM is a paged register. The VREF_TRIM command is used to apply a fixed offset voltage to the reference voltage. It is most typically used by the end user to trim the output voltage at the time the PMBus interface device is assembled into the end user system. The contents of this register can be stored to non-volatile memory using the STORE_USER_ALL command.

 $V_{\text{REF (offset)}} = \text{VREF}_{\text{TRIM}} \times 2 \text{ mV}$

(16)

The maximum trim range is -20% to +10% of the nominal reference voltage (600 mV) in 2 mV steps. Permissible values range from -120 mV to +60 mV. If a value outside this range is given with this command, the <u>device sets</u> the reference voltage to the upper or lower limit depending on the direction of the setting, asserts <u>SMBALERT</u> and sets the CML bit in STATUS_BYTE and the invalid data bit in STATUS_CML.

Including settings from both VREF_TRIM and STEP_VREF_MARGIN_x commands, the net permissible reference voltage adjustment range is -180 mV to +60 mV (-30% to +10%). If a value outside this range is given with this command, the <u>device sets</u> the reference voltage to the upper or lower limit depending on the direction of the setting, asserts SMBALERT and sets the CML bit in STATUS_BYTE and the invalid data bit in STATUS_CML.



The reference voltage transition occurs at the rate determined by the TON_RISE command if the transition is executed during soft-start. Any transition in the reference voltage after soft-start is complete occurs at the rate determined by the highest programmable TON_RISE.

COMMAND								VREF	TRIM							
Format							Linear, t	wo's coi	mplemei	nt binary	/					
Bit Position	7	7 6 5 4 3 2 1 0 7 6 5 4 3 2 1 0														0
Access	r/w	r/w r														
Function				High	Byte							Low	Byte			
Default Value	O O								0	0	0	0	0	0	0	0

8.6.1.33 STEP_VREF_MARGIN_HIGH (MFR_SPECIFIC_05) (D5h)

STEP_VREF_MARGIN_HIGH is a paged register. The STEP_VREF_MARGIN_HIGH command sets the target voltage which the reference voltage changes to when the OPERATION command is set to "Margin High". The contents of this register can be stored to non-volatile memory using the STORE_USER_ALL command.

The actual reference voltage commanded by a margin high command can be found by:

 $V_{\text{REF}(MH)} = (\text{STEP}_{\text{VREF}} \text{MARGIN}_{\text{HIGH}} + \text{VREF}_{\text{TRIM}}) \times 2 \text{ mV}$

The margin high range is 0% to 10% of the nominal reference voltage (600 mV) in 2-mV steps. Permissible values range from 0 mV to 60 mV. If a value outside this range is given with this command, the device sets the reference voltage to the upper or lower limit depending on the direction of the setting, asserts SMBALERT and sets the CML bit in STATUS_BYTE and the invalid data bit in STATUS_CML.

Including settings from both VREF_TRIM and STEP_VREF_MARGIN_x commands, the net permissible reference voltage adjustment range is -180 mV to 60 mV (-30% to 10%). If a value outside this range is given with this command, the device sets the reference voltage to the upper or lower limit depending on the direction of the setting, asserts SMBALERT and sets the CML bit in STATUS_BYTE and the invalid data bit in STATUS_CML.

The reference voltage transition occurs at the rate determined by the TON_RISE command if the transition is executed during soft-start. Any transition in the reference voltage after soft-start is complete occurs at the rate determined by the highest programmable TON_RISE.

COMMAND							STEP	_VREF_	MARG	IN_HIG	н					
Format							Linear,	, two's co	omplem	ent bina	ary					
Bit Position	7	7 6 5 4 3 2 1 0 7 6 5 4 3 2 1 0														0
Access	r	r r r r r r r r r r r r/w r/w r/w r/w r/														r/w
Function				Hig	h Byte							Low	v Byte			
Default Value	0	0 0 0 0 0 0 0 0 0 0 1 1 1 1													0	

The default value of STEP_VREF_MARGIN_HIGH is 30 (dec). This corresponds to a default margin high voltage of 60 mV (\pm 10%) .

8.6.1.34 STEP_VREF_MARGIN_LOW (MFR_SPECIFIC_06) (D6h)

STEP_VREF_MARGIN_LOW is a paged register. The STEP_VREF_MARGIN_LOW command sets the target voltage which the reference voltage changes to when the OPERATION command is set to "Margin Low". The contents of this register can be stored to non-volatile memory using the STORE_USER_ALL command.

The actual output voltage commanded by a margin high command is shown in Equation 18.

 $V_{\text{REF}(ML)} = (\text{STEP}_V\text{REF}_MARGIN}LOW + V\text{REF}_TRIM) \times 2 \text{ mV}$

(18)

(17)

The margin low range is -20% to 0% of the nominal reference voltage (600 mV) in 2-mV steps. Permissible values range from -120 mV to 0 mV. If a value outside this range is given with this command, the device sets the reference voltage to the upper or lower limit depending on the direction of the setting, asserts SMBALERT and sets the CML bit in STATUS_BYTE and the invalid data bit in STATUS_CML.



TPS40422 ZHCS614F – OCTOBER 2011 – REVISED JANUARY 2017

Including settings from both VREF_TRIM and STEP_VREF_MARGIN_x commands, the net permissible reference voltage adjustment range is -180 mV to 60 mV (-30% to +10%). If a value outside this range is given with this command, the device sets the reference voltage to the upper or lower limit depending on the direction of the setting, asserts SMBALERT and sets the CML bit in STATUS_BYTE and the invalid data bit in STATUS_CML.

The reference voltage transition occurs at the rate determined by the TON_RISE command if the transition is executed during soft-start. Any transition in the reference voltage after soft-start is complete occurs at the rate determined by the highest programmable TON_RISE.

COMMAND		STEP_VREF_MARGIN_LOW														
Format		Linear, two's complement binary														
Bit Position	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0
Access	r/w	r	r	r	r	r	r	r	r	r	r/w	r/w	r/w	r/w	r/w	r/w
Function				High	Byte							Low	Byte			
Default Value	1	1 1 1 1 1 1 1 1 1 1 1 1 1 0 0 1 0									0					

The default value of STEP_VREF_MARGIN_LOW is -30 (dec). This corresponds to a default margin low voltage of -60 mV (\pm 10%).

8.6.1.35 PCT_VOUT_FAULT_PG_LIMIT (MFR_SPECIFIC_07) (D7h)

PCT_VOUT_FAULT_PG_LIMIT is a paged register. The PCT_VOUT_FAULT_PG_LIMIT command is used to set the PGOOD, VOUT_UNDER_VOLTAGE (UV) and VOUT_OVER_VOLTAGE (OV) limits as a percentage of nominal.

In two-phase mode, the user can write to PAGE 0 (channel 1) only. Any writes to PAGE 1 are not acknowledged.

The PCT_VOUT_FAULT_PG_LIMIT takes a one byte data word formatted as shown below:

COMMAND		PCT_VOUT_FAULT_PG_LIMIT										
Format		Unsigned binary										
Bit Position	7	6	5	4	3	2	1	0				
Access	r	r	r	r	r	r	r/w	r/w				
Function	Х	Х	Х	Х	Х	Х	PCT_MSB	PCT_LSB				
Default Value	0	0	0	0	0	0	0	0				

The PGOOD, VOUT_UNDER_VOLTAGE (UV) and VOUT_OVER_VOLTAGE (OV) settings are shown in Table 7, as a percentage of nominal reference voltage on the FBx pins.

) -		
PCT_MSB	PCT_LSB	UV	PGL LOW	PGL HIGH	PGH HIGH	PGH LOW	ov
0	0	-16.67%	-12.5%	-8.33%	12.50%	8.33%	16.67%
0	1	-12.50%	-8.33%	-4.17%	8.33%	4.17%	12.50%
1	0	-29.17%	-20.83%	-16.67%	8.33%	4.17%	12.50%
1	1	-41.67%	-37.50%	-33.33%	8.33%	4.17%	12.50%

Table 7. Protection Settings

The PGOOD pin can be tripped if the output voltage is too high (using PGH high) or too low (using PGL low). Additionally, the PGOOD pin has hysteresis. When the output trips PGOOD going low (at PGL low), the output must rise past PGL high before PGOOD is reset. Likewise, when the output trips PGOOD going high (at PGH high), the output must lower past PGH low before PGOOD is reset.

Additionally, when output overvoltage (OV) is tripped, the output must lower below the PGH low threshold, before PGOOD and OV are reset. Likewise, when output undervoltage (UV) is tripped, the output must rise above the PGOOD high threshold, before PGOOD and UV are reset.

8.6.1.36 SEQUENCE_TON_TOFF_DELAY (MFR_SPECIFIC_08) (D8h)

SEQUENCE_TON_TOFF_DELAY is a paged register. The SEQUENCE_TON_TOFF_DELAY command is used to set the delay for turning on the device and turning off the device as a ratio of TON_RISE.

In two-phase mode, the user can only write to PAGE 0 (channel 1). Any writes to PAGE 1 is not acknowledged.

COMMAND				SEQUENC							
COMIMAND				SEQUENC		F_DELAT					
Format		Unsigned binary									
Bit Position	7	6	5	4	3	2	1	0			
Access	r/w	r/w	r/w	r	r/w	r/w	r/w	r			
Function		TON_DELAY	(Х		TOFF_DE	LAY	Х			
Default Value	0	0	0	0	0	0	0	0			

The SEQUENCE_TON_TOFF_DELAY takes a one byte data word formatted as shown below:

TON_DELAY:

This parameter selects the delay from when the output is enabled until soft-start beings, as a multiple of the TON_RISE time. The default value is 0. Values can range from 0 to 7 in increments of 1.

TOFF_DELAY:

This parameter selects the delay from when the output is disabled until the output stops switching, as a multiple of the TON_RISE time. The default value is 0. Values can range from 0 to 7 in increments of 1.

8.6.1.37 OPTIONS (MFR_SPECIFIC_21) (E5h)

The OPTIONS register can be used for setting user selectable options, as shown below.

COMMAND		OPTIONS														
Format		Unsigned binary														
Bit Position	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0
Access	r	r	r	r	r	r	r	r	r	r	r	r	r	r/w	r/w	r/w
Function	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	EN_ADC_CNTL	CH2_DTC	CH1_DTC
Default Value	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0

The contents of this register can be stored to non-volatile memory using the STORE_USER_ALL command.

A "1" in any of these bit positions indicates that:

EN_ADC_CNTL:

Enables ADC operation used for voltage, current and temperature monitoring.

CH2_DTC:

Increases the non-overlap dead time for gate drivers on channel 2.

CH1_DTC:

Increases the non-overlap dead time for gate drivers on channel 1.

8.6.1.38 DEVICE_CODE (MFR_SPECIFIC_44) (FCh)

The DEVICE_CODE command returns a two byte unsigned binary 12-bit device identifier code and 4-bit revision code in the following format.

COMMAND								MFF	SPECI	FIC_44						
Format		Linear, two's complement binary														
Bit Position	7	6	6 5 4 3 2 1 0 7 6 5 4 3 2 1 0													
Access	r	r	r	r	r	r	r	r	r	r	r	r	r	r	r	r
Function						Iden	tifier Co	ode						Revisio	n Code	
Default Value	0	0 0 0 0 0 0 0 0 0 0 1 1 0 0 0														

This command is oriented toward providing similar information to the DEVICE_ID command but for devices that do not support block read and write functions.

8.6.1.38.1 Identifier Code

Fixed at 7 (dec).

8.6.1.38.2 Revision Code

Fixed at 4 (dec).

9 Application and Implementation

NOTE

Information in the following applications sections is not part of the TI component specification, and TI does not warrant its accuracy or completeness. TI's customers are responsible for determining suitability of components for their purposes. Customers should validate and test their design implementation to confirm system functionality.

9.1 Application Information

This design example describes the design process and component selection for a dual-output, synchronous buck, DC/DC converter using the device. The design goal parameters are listed in Table 8.

The design procedure provides calculations for channel 1 only.

9.2 Typical Application

9.2.1 Dual-Output Converter



Typical Application (continued)





Typical Application (continued)

9.2.1.1 Design Requirements

For this design example, use the following input parameters.

	PARAMETER	TEST CONDITION	MIN	TYPE	MAX	UNIT
V _{IN}	Input voltage		8	12	14	V
V _{IN(ripple)}		I _{OUT} = 20 A		0.2		V
V _{OUT}	Output voltage			1.2		V
	Line regulation	$8 \text{ V} \le \text{V}_{\text{IN}} \le 14 \text{ V}$			0.5%	
	Load regulation	$0 \text{ A} \le I_{\text{OUT}} \le 20 \text{ A}$			0.5%	
V _{P-P}	Output ripple voltage	I _{OUT} = 20 A		30		mV
ΔV_{OUT}	Output voltage deviation during load transient	V _{IN} = 12 V, I _{OUT} = 10 A		60		mV
I _{OUT}	Output current	$8 \text{ V} \leq \text{V}_{\text{IN}} \leq 14 \text{ V}$			20	А
t _{SS}	Soft-start time			2.7		ms
η	Efficiency	V _{IN} = 12 V, I _{OUT} = 20 A		88%		
f _{SW}	Switching frequency			500		kHz

Table 8. Design Parameters

9.2.1.2 Detailed Design Procedure

9.2.1.2.1 Custom Design with WEBENCH® Tools

Click here to create a custom design using the TPS40422 device with the WEBENCH® Power Designer.

- 1. Start by entering the input voltage (V_{IN}), output voltage (V_{OUT}), and output current (I_{OUT}) requirements.
- 2. Optimize the design for key parameters such as efficiency, footprint, and cost using the optimizer dial.
- 3. Compare the generated design with other possible solutions from Texas Instruments.
- The WEBENCH Power Designer provides a customized schematic along with a list of materials with real time pricing and component availability. In most cases it offers the ability to:
- In most cases, these actions are available:
 - Run electrical simulations to see important waveforms and circuit performance
 - Run thermal simulations to understand board thermal performance
 - Export customized schematic and layout into popular CAD formats
 - Print PDF reports for the design, and share design with colleagues
- Get more information about WEBENCH tools at www.ti.com/WEBENCH.

9.2.1.2.2 Step 1: Inductor Selection

The inductor is determined by the desired ripple current. The required inductor is calculated using Equation 19.

$$L = \frac{V_{IN(max)} - V_{OUT}}{I_{RIPPLE}} \times \frac{V_{OUT}}{V_{IN(max)}} \times \frac{1}{f_{SW}} = \frac{14 V - 1.2 V}{0.2 \times 20 A} \times \frac{1.2}{14 V} \times \frac{1}{500 \text{ kHz}} = 0.55 \ \mu\text{H}$$
(19)

Usually the peak-to-peak inductor current I_{RIPPLE} is selected to be approximately 20% of the maximum rated output current. Considering the variation and derating of inductance, the practical inductor choice specifications are:

- Inductance: 0.82 µH
- Current rating: 27 A
- DCR: 0.9 mΩ
- Manufacturer: Wurth

$$I_{\text{RIPPLE}} = \frac{V_{\text{OUT}}}{V_{\text{IN}(\text{max})} \times f_{\text{SW}}} \times \frac{V_{\text{IN}(\text{max})} - V_{\text{OUT}}}{L} = \frac{1.2 \text{ V}}{14 \text{ V} \times 500 \text{ kHz}} \times \frac{14 \text{ V} - 1.2 \text{ V}}{0.82 \text{ }\mu\text{H}} = 2.68 \text{ A}$$
(20)



Using the chosen inductor, the real inductor ripple current is 2.68 A. Equation 21 calculates the inductor RMS current which is 20.02 A based on $I_{OUT} = 20$ A and $I_{RIPPLE} = 2.68$ A.

$$I_{L(rms)} = \sqrt{I_{OUT (max)}^{2} + \left(\frac{1}{12}\right) \times (I_{RIPPLE})^{2}} = \sqrt{(20 \text{ A})^{2} + \left(\frac{1}{12}\right) \times (2.68 \text{ A})^{2}} = 20.02 \text{ A}$$
(21)

Equation 22 computes the peak current.

$$I_{L(\text{peak})} = I_{\text{OUT}} + \frac{1}{2} \times I_{\text{RIPPLE}} = 20 \text{ A} + \frac{1}{2} \times 2.68 \text{ A} = 21.34 \text{ A}$$
(22)

TPS40422 ZHCS614F – OCTOBER 2011 – REVISED JANUARY 2017



(23)

9.2.1.2.3 Step 2: Output Capacitor Selection

The output capacitor is typically selected by the output load transient-response requirement and by allowable output voltage ripple.

- The output capacitor must supply the load with the required current when it is not immediately provided by the regulator. When the output capacitor supplies load current, the impedance of the capacitor affects the magnitude of voltage deviation during the transient.
- The ripple voltage developed across the output capacitor is due to the ripple current in the capacitor and in turn the ripple current is usually due to either the ESR or the value of the capacitor. The ESR of aluminum electrolytics and most tantalums are too high to allow for effective ripple reduction. Often, a combination of several electrolytic capacitors have to be paralleled to obtain large enough value of capacitance with low enough ESR in addition to several ceramic capacitors that offer much lower ESR but at the price of lower capacitance value.

Equation 23 calculates the minimum output capacitance needed to satisfy overvoltage and undervoltage requirements during the load step. In practical design to account for de-rating and variation it is strongly recommended to multiply the calculated capacitance value by a factor between 1.5 and 5 based on the tests in the actual circuit. In this example, two 330- μ F polymer capacitors with ESR of 15 m Ω were chosen as well as three 100- μ F ceramic capacitor with ESR of 3 m Ω . The total equivalent capacitance C_{OUT} is 1004 μ F. The additional 0.1- μ F capacitor (C₃₈ and C₃₉) is used for filtering of high frequency noise.

$$C_{OUT \,(min\,)} = \frac{\left(I_{TRAN \,(min\,)}\right)^2 \times L}{2 \times V_{OUT} \times \Delta V_{OUT}} = \frac{(10 \text{ A})^2 \times 0.82 \,\mu\text{H}}{2 \times 1.2 \,\text{V} \times 60 \,\text{mV}} = 569.4 \,\mu\text{F}$$

where

- I_{TRAN(min)} is the load transient step
- ΔV_{OUT} is the output voltage deviation during load transient
- C_{OUT(minM)} is the minimum required capacitance

Using the known target output capacitance value, Equation 24 calculates the maximum ESR allowed to meet the output voltage ripple specification.

$$\text{ESR}_{\text{MAX}} = \frac{V_{\text{OUT (ripple)}} - \left(\frac{I_{\text{RIPPLE}}}{8 \times f_{\text{SW}} \times C_{\text{OUT}}}\right)}{I_{\text{RIPPLE}}} = \frac{30 \text{ mV} - \left(\frac{2.68 \text{ A}}{8 \times 500 \text{ kHz} \times 1004 \text{ }\mu\text{F}}\right)}{2.68 \text{ A}} = 11 \text{ m}\Omega$$
(24)

9.2.1.2.4 Step 3: Input Capacitance Selection

The input capacitance is selected to handle the ripple current of the buck stage, when the high-side MOSFET switches on, while maintaining the ripple voltage on the supply line low. The input voltage ripple depends on input capacitance and ESR. The minimum capacitor and the maximum ESR can be estimated using the Equation 25 and Equation 26 because the input ripple is composed of a capacitive portion, $V_{\text{RIPPLE(CIN)}}$, and a resistive portion, $V_{\text{RIPPLE(ESR)}}$. In this case, the allowed ripple for the capacitive portion is 0.1 V and for the resistive portion is 0.1 V.

$$C_{IN(min)} = \frac{I_{OUT(max)} \times V_{OUT}}{V_{RIPPLE(CIN)} \times V_{IN(max)} \times f_{SW}} = \frac{20 \text{ A} \times 1.2 \text{ V}}{0.1 \text{ V} \times 14 \text{ V} \times 500 \text{ kHz}} = 34 \text{ }\mu\text{F}$$
(25)

$$ESR_{CIN (max)} = \frac{V_{RIPPLE (ESR)}}{I_{OUT} + (1/2) \times I_{RIPPLE}} = \frac{0.1 V}{20A + (1/2) \times 2.68A} = 4.68 m\Omega$$
(26)

For this design example, five 22- μ F, 25-V ceramic capacitors and two 330- μ F, 25-V electrolytic capacitors were selected in parallel for the power stage with sufficient margin. The electrolytic capacitors provide better stability during load transients by supplying enough current to the controller.

9.2.1.2.5 Step 4: MOSFET Selection

The MOSFET selection determines the converter efficiency. In this design, the duty cycle is very small so that the high-side MOSFET is dominated in switching losses and the low-side MOSFET is dominated with conduction losses. To optimize efficiency, choose smaller gate charge for the high-side MOSFET and smaller $R_{DS(on)}$ for the low-side MOSFET.

The MOSFETs were selected and their parameters are listed in Table 9.

MOSFET	DEVICE NUMBER	V-RATING (V)	ON-RESISTANCE R _{DS(on)} (mΩ)	GATE CHARGE QG (nC)
High-side	CSD87350Q5D	30	5	8.4
Low-side	CSD87350Q5D	30	1.2	20

Table 9. MOSFET Selection

9.2.1.2.6 Step 5: Snubber Circuit Design

The purpose of the snubber network is to damp the high frequency ringing on the switch node and reduce the peak voltage stress on the low-side FET. A quick and efficient way to design a snubber network is to base it off the allowable power budget to be dissipated. A best practice is to target power dissipation in the output snubber between 0.25% and 0.5% of total power. Normally, the R-C time constant is designed to be short enough such that the capacitor is fully charged or discharged before the next switching edge. In this case, the power dissipation in the snubber resistor is determined only by the capacitor value and independent of the resistor value.

$$\mathbf{E} = \left(\frac{1}{2}\right) \times \mathbf{C}_{\mathrm{S}} \times (\mathbf{V}_{\mathrm{P}})^{2}, \qquad \mathbf{P} = \frac{2 \times \mathbf{E}}{\mathbf{t}_{\mathrm{S}}} = \mathbf{C}_{\mathrm{S}} \times \frac{(\mathbf{V}_{\mathrm{P}})^{2}}{\mathbf{t}_{\mathrm{S}}} = \mathbf{C}_{\mathrm{S}} \times \mathbf{f}_{\mathrm{SW}} \times (\mathbf{V}_{\mathrm{P}})^{2}$$

where

- peak voltage stored on the capacitors between pulse edges
- t_s is the period
- f_{SW} is the switching frequency
- C_S is the snubber capacitor

The power budget is $1.2 \text{ V} \times 20 \text{ A} \times 0.25\% = 60 \text{ mW}$ and because the switching frequency is 500 kHz with peak voltage of 14 V, the calculated effective snubber capacitor is 612pF. In this example, to make sure that the ringing is critically damped, a practical value is chosen to be 1000pF for C₃₄ and C₃₅.

In order to determine the resistor value, the fully charge and discharge time $5 \times R \times C$ is set to 10% of the shortest pulse width. Shortest pulse width can be determined using Equation 28.

$$t_{\rm ON} = \frac{V_{\rm OUT}}{V_{\rm IN\,(max\,)}} \times \frac{1}{f_{\rm SW}} = \frac{1.2 \text{ V}}{14 \text{ V}} \times \frac{1}{500 \text{ kHz}} = 171.4 \text{ ns}$$
(28)

In this design example, three 10- Ω resistors were chosen in parallel to obtain the calculated value and desired form factor. In the EVM schematic, the resistors are R₃₀, R₃₃, R₂₀ and R₂₉, R₂₈, R₂₆.

9.2.1.2.7 Step 6: Soft-Start Time

The TON_RISE command sets the time in milliseconds, from when the output starts to rise until the voltage has entered the regulation band. Charging current for the output capacitors needs to be considered when selecting the soft-start time. Based on the output capacitance and output voltage in this example, use Equation 29 to calculate the output capacitor charging current.

$$I_{CAP} = \frac{V_{OUT} \times C_{OUT}}{t_{SS}} = \frac{1.2 \text{ V} \times 1004 \text{ }\mu\text{F}}{2.7 \text{ }m\text{s}} = 0.45 \text{ A}$$
(29)

9.2.1.2.8 Step 7: Peripheral Component Design

9.2.1.2.8.1 RT (Pin 1) Switching Frequency Setting

$$R_{\rm RT} = \frac{20 \times 10^9}{f_{\rm SW}} = \frac{20 \times 10^9}{500 \times 10^3} = 4 \text{ k}\Omega$$
(30)

In the PWR091EVM schematic, a practical value of 40.2 k Ω was chosen to set the frequency.

(27)

9.2.1.2.8.2 FB1 (Pin 2) and FB2 (Pin 8) Output Voltage Setting

A feedback divider between the DIFFO pin and AGND sets the output voltage. The components in Figure 9 that determine the nominal output voltage are R_1 and R_2 .

Calculation for 1.2-V output: Select the high-side resistor (R1) to be 47.5 kΩ and use Equation 31 to calculate low-side resistor R₂.

$$R_2 = V_{FB} \times \frac{R_1}{V_{OUT} - V_{FB}} = 0.6 \text{ V} \times \frac{47.5 \text{ k}\Omega}{1.2 \text{ V} - 0.6 \text{ V}} = 47.5 \text{ k}\Omega$$

where

- V_{FB} is the feedback voltage of 600 mV
- V_{OUT} is the desired output voltage of 1.2 V
- R1 and R2 are resistors for the voltage divider from the output to the feedback

(31)

9.2.1.2.8.3 Compensation Network Using COMP1 (Pin 3), COMP2 (Pin 7), FB1 (Pin 2) FB2 DIFFO1 (Pin 8) (Pin 39)

The device uses voltage mode control topology in a single phase dual-output configuration. In this example, a Type III compensation network is implemented to compensate for the double pole, close the loop and stabilize the system. TI provides a compensation calculator tool to streamline the compensation design process.

The Loop Compensation Tool (SLUC263) provides the recommended compensation components as a starting point and approximate bode plots. It is always recommended to measure the real system bode plot after the design and adjust the compensation values accordingly. The chosen compensation values are derived from the tool calculation along with the Venable K-factor method and optimization based on the measured data.

- $R_1 = R_2 = 47.5 \text{ k}\Omega$
- $R_3 = 4.75 \text{ k}\Omega$
- R₄ = 20 kΩ
- $C_1 = 470 \text{ pF}$
- $C_2 = 1.2 \text{ nF}$
- $C_3 = 120 \text{ pF}$

1

In this design example, the desired crossover frequency chosen is approximately 4 x f_{DP} (20 kHz). Use Equation 32 to calculate the double pole frequency formed by the output inductor and capacitor bank.

$$f_{DP} = \frac{1}{2\pi \times \sqrt{LC}} = \frac{1}{2\pi \times \sqrt{820 \text{ nH} \times 1004 \,\mu\text{F}}} = 5547 \text{ Hz}$$
(32)

Because the Venable K-factor method was used to derive these compensation values, it is important to ensure that the poles and zeroes are coincident. A way to confirm that the poles and zeroes are coincident is to calculate the poles and zeroes from the gain of the Type-III compensation network.

$$GAIN_{TYPE -3} = \frac{R_1 + R_3}{R_1 \times R_3 \times C_3} \times \frac{\left(s + \frac{1}{R_4 \times C_2}\right) \times \left(s + \frac{1}{(R_1 + R_3) \times C_1}\right)}{s \times \left(s + \frac{C_2 + C_3}{R_4 \times C_3 \times C_2}\right) \times \left(s + \frac{1}{R_3 \times C_1}\right)}$$
(33)

The first and second zeroes should yield approximately equal frequency values of 6480 Hz and 6631 Hz.

1

$$f_{Z1} = \frac{1}{2\pi \times (R_1 + R_3) \times C_1} = \frac{1}{2\pi \times (47.5 \text{ k}\Omega + 4.75 \text{ k}\Omega) \times 470 \text{ pF}} = 6480 \text{ Hz}$$
(34)

$$f_{Z2} = \frac{1}{2\pi \times R_4 \times C_2} = \frac{1}{2\pi \times 20 \text{ k}\Omega \times 1.2 \text{ nF}} = 6631 \text{ Hz}$$
(35)

Analogous to the zeroes being coincident, the first and second poles are coincident as well and are shown in Equation 36 and Equation 37.

$$f_{P1} = \frac{1}{2\pi \times R_3 \times C_1} = \frac{1}{2\pi \times 4.75 \text{ k}\Omega \times 470 \text{ pF}} = 71290 \text{ Hz}$$
(36)



www.ti.com.cn



(37)

$$f_{P2} = \frac{1}{2\pi \times \left(\frac{R_4 \times C_2 \times C_3}{C_2 + C_3}\right)} = \frac{120 \text{ pF} + 1.2 \text{ nF}}{2\pi \times 20 \text{ k}\Omega \times 120 \text{ pF} \times 1.2 \text{ nF}} = 72946 \text{ Hz}$$

The resulting compensated system Bode plot is shown in Figure 20 and the PWR091 EVM user guide (SLVU638). A more comprehensive discussion is presented in *Under the Hood of Low-Voltage DC/DC Converters* from the 2003 TI Power Supply Seminar (SLUP206).

9.2.1.2.8.4 Remote Sensing Using VSNS1 (Pin 37), GSNS1 (Pin 38), VSNS2 (Pin 15), and GSNS2 (Pin 14)

The integrated differential amplifier facilitates remote sensing when VSNSx pin(s) and GSNSx pin(s) are configured as the positive and negative inputs. Connect these pins remotely to the load through low-value resistors to the output connector. Including these resistors prevents damage due to potential large negative voltage on output. Standard values chosen for these resistors are between 10 Ω and 50 Ω , depending on the upper and lower values which are based on error in the bias current and power dissipation. The capacitor between the positive and negative sense lines of 1000 pF is added for additional filtering of the noise that could form because the sense lines are typically long.

9.2.1.2.8.5 Temperate Sensing Using TSNS1 (Pin36) and TSNS2 (Pin 16)

The temperature sensing is accomplished using the relationship between base-emitter voltage and collector current. Local bypass capacitors are recommended for both TSNSx pins. In this design example, the recommended value for both bypass capacitors (C_{30} and C_{31}) is 1000 pF.

9.2.1.2.8.6 Current Sensing Network Design Using CS1P (Pin 34), CS1N (Pin 35), CS2P (Pin 18), and CS2N (Pin 17)

In this design, current sensing is accomplished using the series resistance of the inductor. In order to do this, a large AC switching voltage forced across the inductor must be filtered out so that the measured voltage is only a DC drop. This filter is implemented via an R-C network directly across the output inductor. The R-C network is chosen such that it provides enough filtering for the application, but in this case the resistor value cannot exceed 2 k Ω in order to keep the error from the CSxN and CSxP pin bias current to a minimum. Also, the time constant of the filter has to match the time constant of the output inductor. Based on the component labels in Figure 10, the following equation computes the capacitor value.

$$C_4 = \frac{L}{R_{DCR} \times R_5} = \frac{0.82 \ \mu H}{0.9 \ m\Omega \times 2 \ k\Omega} = 0.455 \ \mu F$$
(38)

A practical capacitor value for the EVM was chosen to be 0.47 μ F. The capacitor C₂₇ and C₂₃ should be placed as close to the CSxP and CSxN pins as possible to provide good bypass filtering. R₅ and R₆ should be placed close to the inductor to prevent traces with the switch node voltage from being propagated across the board and getting close to sensitive pins.

9.2.1.2.8.7 PMBus Address ADDR1 (Pin 9), and ADDR0 (Pin 10)

These two pins are tied to resistors shown in Table 1 based on the desired digit combination that sets specific address for the PMBus protocol to read it. In this design example, a practical resistor value of $36.5k\Omega$ (R₈ and R₉) was chosen to set the address.

9.2.1.2.8.8 Voltage Decoupling Capacitors

This device offers four pins that are available for DC bias voltage and each requires a small decoupling capacitor for proper functionality

9.2.1.2.8.8.1 VDD (Pin 31)

This device offers four pins that are available for DC bias voltage and each requires a small decoupling capacitor for proper functionality

9.2.1.2.8.8.2 BP3 (Pin 32)

This application requires a $1-\mu F$ ceramic capacitor (C₁₂) for the internal regulator that supplies to the internal control of the device. Minimum allowed capacitance is 100 nF.



9.2.1.2.8.8.3 BNEXT (Pin 24)

This application requires a 0.1- μ F ceramic capacitor (C₉) and a 10 k Ω resistor (R₄₀) places in parallel to discharge the capacitor.

9.2.1.2.8.8.4 BP6 (Pin 25)

This application requires a $1-\mu F$ ceramic capacitor (C₁₀) for the internal regulator that supplies power to the gate drivers.

9.2.1.2.8.8.5 Power Good PGOOD1 (Pin 33), PGOOD2 (Pin 19)

This application requires the PGOODx pin to be connected to the BP3 pin with a 10-k Ω resistor (R₃₇ and R₁₉)

9.2.1.2.8.8.6 Bootstrap Capacitors BOOT1 (Pin 30), and BOOT2 (Pin 20)

This application requires a bootstrap capacitor connected between the BOOT1 pin and the SW1 pin and between the BOOT2 pin and the SW2 pin. The value of the bootstrap capacitor depends on the total gate charge of the high-side MOSFET and the amount of droop allowed on the bootstrap capacitor.

$$C_{BOOT} = \frac{Q_G}{\Delta V} = \frac{8.4 \text{ nC}}{0.2 \text{ V}} = 42 \text{ nF}$$
(39)

For this application, a standard value of 100 nF is chosen for the capacitors C_1 and C_5 . In addition, series resistors (R1 and R4) are added to reduce the turn on speed of the high-side MOSFET and control the ringing. This resistor has only a limited effect because at the beginning of the HDRVx gate pulse, when the absolute value of gate voltage is still less than BP6, most of the gate current comes directly from BP6 instead of from the BOOT capacitor.

9.2.1.2.8.8.7 High-Side MOSFET (Gate) Resistor

In order to reduce the voltage spike on switching node further, it is recommended to add a high-side gate resistor and use a Schottky diode in parallel with the resistor (connect anode to gate, and connect cathode to driver) to maintain fast turn off. This application requires a Schottky diode If the gate resistor is more than 3 Ω , so as not to interfere with the anti-cross-conduction circuit.

The MOSFET resistor and Schottky diode are not presented on design sample, but they are recommended if the voltage spike on switching node or BOOT pin is above the absolute maximum rating and need to be reduced to avoid device failure.

9.2.1.2.8.8.8 Synchronization Setting SYNC (Pin 40)

This pin serves as a logic level input for external clock synchronization. A standard resistor value of 49.9 Ω is chosen for measurement purposes between TP17 and TP4.

9.2.1.2.8.8.9 BP6 (Pin 25)

The place holder for R34 resistor is used in the case of two-phase mode. This resistor ties the FB2 pin to the BP6 pin.

9.2.1.2.8.8.10 DIFFO (Pin 39)

Connected a 49.9- Ω series resistor within in the feedback loop to the DIFFO pin, This resistor is for loop response analysis and it is accessible at the test points for V_{OUT1} (test points TP9 and TP8) and V_{OUT2} (test points TP10 and TP9).



9.2.1.3 Application Curves



TEXAS INSTRUMENTS

www.ti.com.cn

TPS40422





10 Power Supply Recommendations

This device is designed to operate from an input voltage supply between 4.5 V and 20 V. There is also input voltage and switch node voltage limitation from MOSFET. The proper bypassing of input supplies is critical for noise performance. See the MOSFET datasheet for more information.



11 Layout

11.1 Layout Guidelines

11.1.1 PCB Layout Guidelines

Layout is a critical portion of good power supply design. Below are the PCB layout considerations for device .

- If the analog ground (AGND) and power ground (PGND) are separated on the board, the power stage and
 related components should be terminated or bypassed to the power ground. Signal components of device
 should be terminated or bypassed to the analog ground. Connect the thermal pad of the device to power
 ground plane through sufficient vias. Connect AGND and PGND pins of the device to the thermal pad directly.
 The connection between AGND pin and thermal pad serves as the only connection between analog ground
 and power ground.
- If one common ground is used on the board, the device and related components must be placed on a noise quiet area which is isolated from fast switching voltage and current paths.
- Maintain placement of signal components and regulator bypass capacitors local to the device. Place them as
 close as possible to the pins to which they are connected. These components include the feedback resistors,
 frequency compensation, the RT resistor, ADDR0 and ADDR1 resistors, as well as bypass capacitors for
 BP3, BP6, and VDD.
- The VSNSx and GSNSx are remotely connected to the load through low ohm resistors, and they must be routed as a differential pair on noise quiet area. Place a high-frequency bypass capacitor between the VSNSx pin and the GSNSx pin, and place the capacitor close to the device.
- The CSxP pin and CSxN pin must be routed as a differential pair on noise quiet area. The resistor of R-C
 network should be placed close to inductor. The capacitor between CSxP pin and CSxN pin must be placed
 as close as possible to the device.
- Place the thermal transistor close to the inductor. A bypass capacitor with a value of 1-nF or larger must be placed close to the transistor. Use a separate ground trace for the transistor.

11.1.2 MOSFET Layout Guidelines

Below are the MOSFET layout considerations for. Please refer to the datasheet of the MOSFET for more layout information.

- Input bypass capacitors should be physically as close as possible to the VIN and GND pins of the MOSFET device. In addition, a high-frequency bypass capacitor on the MOSFET input voltage pins can help to reduce switching ringing.
- Minimize the SW copper area for best noise performance. Route sensitive traces away from SW, as it contains fast switching voltage and lends easily to capacitive coupling.

TPS40422 ZHCS614F – OCTOBER 2011 – REVISED JANUARY 2017



www.ti.com.cn

11.2 Layout Example



Figure 28. PCB Layout Recommendation



12 器件和文档支持

12.1 器件支持

• 《系统管理总线 (SMBus) 技术规范》,版本 2.0, SBS 开发者论坛, 2000 年 8 月 3 日 (http://smbus.org/)

12.2 社区资源

The following links connect to TI community resources. Linked contents are provided "AS IS" by the respective contributors. They do not constitute TI specifications and do not necessarily reflect TI's views; see TI's Terms of Use.

TI E2E[™] Online Community *TI's Engineer-to-Engineer (E2E) Community.* Created to foster collaboration among engineers. At e2e.ti.com, you can ask questions, share knowledge, explore ideas and help solve problems with fellow engineers.

Design Support TI's Design Support Quickly find helpful E2E forums along with design support tools and contact information for technical support.

12.3 商标

E2E is a trademark of Texas Instruments. WEBENCH is a registered trademark of Texas Instruments. PMBus is a trademark of SMIF, Inc.. All other trademarks are the property of their respective owners.

12.4 静电放电警告



这些装置包含有限的内置 ESD 保护。存储或装卸时,应将导线一起截短或将装置放置于导电泡棉中,以防止 MOS 门极遭受静电损 伤。

12.5 Glossary

SLYZ022 — TI Glossary.

This glossary lists and explains terms, acronyms, and definitions.

13 机械、封装和可订购信息

以下页面包括机械、封装和可订购信息。这些信息是指定器件的最新可用数据。这些数据发生变化时,我们可能不 会另行通知或修订此文档。如欲获取此产品说明书的浏览器版本,请参见左侧的导航栏。



PACKAGING INFORMATION

Orderable Device	Status	Package Type	Package	Pins	Package	Eco Plan	Lead finish/	MSL Peak Temp	Op Temp (°C)	Device Marking	Samples
	(1)		Drawing		Qty	(2)	Ball material	(3)		(4/5)	
				_			(6)				
TPS40422RHAR	ACTIVE	VQFN	RHA	40	2500	RoHS & Green	NIPDAU	Level-3-260C-168 HR	-40 to 125	TPS 40422	Samples
TPS40422RHAT	ACTIVE	VQFN	RHA	40	250	RoHS & Green	NIPDAU	Level-3-260C-168 HR	-40 to 125	TPS 40422	Samples
TPS40422RSBR	ACTIVE	WQFN	RSB	40	3000	RoHS & Green	NIPDAU	Level-2-260C-1 YEAR	-40 to 125	TPS 40422	Samples
TPS40422RSBT	ACTIVE	WQFN	RSB	40	250	RoHS & Green	NIPDAU	Level-2-260C-1 YEAR	-40 to 125	TPS 40422	Samples

⁽¹⁾ The marketing status values are defined as follows:

ACTIVE: Product device recommended for new designs.

LIFEBUY: TI has announced that the device will be discontinued, and a lifetime-buy period is in effect.

NRND: Not recommended for new designs. Device is in production to support existing customers, but TI does not recommend using this part in a new design.

PREVIEW: Device has been announced but is not in production. Samples may or may not be available.

OBSOLETE: TI has discontinued the production of the device.

⁽²⁾ RoHS: TI defines "RoHS" to mean semiconductor products that are compliant with the current EU RoHS requirements for all 10 RoHS substances, including the requirement that RoHS substance do not exceed 0.1% by weight in homogeneous materials. Where designed to be soldered at high temperatures, "RoHS" products are suitable for use in specified lead-free processes. TI may reference these types of products as "Pb-Free".

RoHS Exempt: TI defines "RoHS Exempt" to mean products that contain lead but are compliant with EU RoHS pursuant to a specific EU RoHS exemption.

Green: TI defines "Green" to mean the content of Chlorine (CI) and Bromine (Br) based flame retardants meet JS709B low halogen requirements of <=1000ppm threshold. Antimony trioxide based flame retardants must also meet the <=1000ppm threshold requirement.

⁽³⁾ MSL, Peak Temp. - The Moisture Sensitivity Level rating according to the JEDEC industry standard classifications, and peak solder temperature.

⁽⁴⁾ There may be additional marking, which relates to the logo, the lot trace code information, or the environmental category on the device.

⁽⁵⁾ Multiple Device Markings will be inside parentheses. Only one Device Marking contained in parentheses and separated by a "~" will appear on a device. If a line is indented then it is a continuation of the previous line and the two combined represent the entire Device Marking for that device.

⁽⁶⁾ Lead finish/Ball material - Orderable Devices may have multiple material finish options. Finish options are separated by a vertical ruled line. Lead finish/Ball material values may wrap to two lines if the finish value exceeds the maximum column width.

Important Information and Disclaimer: The information provided on this page represents TI's knowledge and belief as of the date that it is provided. TI bases its knowledge and belief on information provided by third parties, and makes no representation or warranty as to the accuracy of such information. Efforts are underway to better integrate information from third parties. TI has taken and



www.ti.com

10-Dec-2020

continues to take reasonable steps to provide representative and accurate information but may not have conducted destructive testing or chemical analysis on incoming materials and chemicals. TI and TI suppliers consider certain information to be proprietary, and thus CAS numbers and other limited information may not be available for release.

In no event shall TI's liability arising out of such information exceed the total purchase price of the TI part(s) at issue in this document sold by TI to Customer on an annual basis.

PACKAGE MATERIALS INFORMATION

www.ti.com

Texas Instruments

TAPE AND REEL INFORMATION





QUADRANT ASSIGNMENTS FOR PIN 1 ORIENTATION IN TAPE



*All dimensions are nominal												
Device	Package Type	Package Drawing	Pins	SPQ	Reel Diameter (mm)	Reel Width W1 (mm)	A0 (mm)	B0 (mm)	K0 (mm)	P1 (mm)	W (mm)	Pin1 Quadrant
TPS40422RHAR	VQFN	RHA	40	2500	330.0	16.4	6.3	6.3	1.1	12.0	16.0	Q2
TPS40422RHAT	VQFN	RHA	40	250	180.0	16.4	6.3	6.3	1.1	12.0	16.0	Q2
TPS40422RSBR	WQFN	RSB	40	3000	330.0	12.4	5.25	5.25	1.1	8.0	12.0	Q2
TPS40422RSBT	WQFN	RSB	40	250	330.0	12.4	5.25	5.25	1.1	8.0	12.0	Q2

TEXAS INSTRUMENTS

www.ti.com

PACKAGE MATERIALS INFORMATION

16-Feb-2017



*All dimensions are nominal

Device	Package Type	Package Drawing	Pins	SPQ	Length (mm)	Width (mm)	Height (mm)
TPS40422RHAR	VQFN	RHA	40	2500	367.0	367.0	38.0
TPS40422RHAT	VQFN	RHA	40	250	210.0	185.0	35.0
TPS40422RSBR	WQFN	RSB	40	3000	338.0	355.0	50.0
TPS40422RSBT	WQFN	RSB	40	250	338.0	355.0	50.0

RHA 40

6 x 6, 0.5 mm pitch

GENERIC PACKAGE VIEW

VQFN - 1 mm max height

PLASTIC QUAD FLATPACK - NO LEAD

This image is a representation of the package family, actual package may vary. Refer to the product data sheet for package details.





RHA0040B



PACKAGE OUTLINE

VQFN - 1 mm max height

PLASTIC QUAD FLATPACK - NO LEAD



NOTES:

- 1. All linear dimensions are in millimeters. Any dimensions in parenthesis are for reference only. Dimensioning and tolerancing per ASME Y14.5M.
- 2. This drawing is subject to change without notice.
- 3. The package thermal pad must be soldered to the printed circuit board for thermal and mechanical performance.



RHA0040B

EXAMPLE BOARD LAYOUT

VQFN - 1 mm max height

PLASTIC QUAD FLATPACK - NO LEAD



 This package is designed to be soldered to a thermal pad on the board. For more information, see Texas Instruments literature number SLUA271 (www.ti.com/lit/slua271).


RHA0040B

EXAMPLE STENCIL DESIGN

VQFN - 1 mm max height

PLASTIC QUAD FLATPACK - NO LEAD



5. Laser cutting apertures with trapezoidal walls and rounded corners may offer better paste release. IPC-7525 may have alternate design recommendations.



RSB 40

5 x 5 mm, 0.4 mm pitch

GENERIC PACKAGE VIEW

WQFN - 0.8 mm max height PLASTIC QUAD FLATPACK - NO LEAD



Images above are just a representation of the package family, actual package may vary. Refer to the product data sheet for package details.



4207182/D

重要声明和免责声明

TI 提供技术和可靠性数据(包括数据表)、设计资源(包括参考设计)、应用或其他设计建议、网络工具、安全信息和其他资源,不保证没 有瑕疵且不做出任何明示或暗示的担保,包括但不限于对适销性、某特定用途方面的适用性或不侵犯任何第三方知识产权的暗示担保。

这些资源可供使用 TI 产品进行设计的熟练开发人员使用。您将自行承担以下全部责任:(1) 针对您的应用选择合适的 TI 产品,(2) 设计、验 证并测试您的应用,(3) 确保您的应用满足相应标准以及任何其他安全、安保或其他要求。这些资源如有变更,恕不另行通知。TI 授权您仅可 将这些资源用于研发本资源所述的 TI 产品的应用。严禁对这些资源进行其他复制或展示。您无权使用任何其他 TI 知识产权或任何第三方知 识产权。您应全额赔偿因在这些资源的使用中对 TI 及其代表造成的任何索赔、损害、成本、损失和债务,TI 对此概不负责。

TI 提供的产品受 TI 的销售条款 (https:www.ti.com.cn/zh-cn/legal/termsofsale.html) 或 ti.com.cn 上其他适用条款/TI 产品随附的其他适用条款 的约束。TI 提供这些资源并不会扩展或以其他方式更改 TI 针对 TI 产品发布的适用的担保或担保免责声明。

> 邮寄地址:上海市浦东新区世纪大道 1568 号中建大厦 32 楼,邮政编码:200122 Copyright © 2021 德州仪器半导体技术(上海)有限公司